

Layer-2 Modules Configuration Commands

Table of Contents

Chapter 1 Physical Feature Configuration Commands	1
1.1 Interface Configuration Commands.....	1
1.1.1 speed.....	1
1.1.2 duplex.....	2
1.1.3 flow-control	2
Chapter 2 Port Protection and Security	4
2.1 Port Protection Commands	4
2.1.1 switchport protected	4
2.2 Port Security Commands.....	4
2.2.1 switchport port-security bind mac.....	5
2.2.2 switchport port-security bind ip.....	5
2.2.3 switchport port-security block mac	6
2.2.4 switchport port-security block ip	7
2.2.5 switchport port-security static mac-address	7
2.2.6 switchport port-security mode static	8
2.2.7 switchport port-security mode dynamic	9
2.2.8 switchport port-security dynamic maximum	9
Chapter 3 Control of Port Block and Storm	11
3.1 Configuration Commands of Port Block	11
3.1.1 switchport block.....	11
3.2 Storm Control Command.....	11
3.2.1 storm-control	12
Chapter 4 Port mirroring	13
4.1 Port Mirroring Configuration Commands.....	13
4.1.1 mirror.....	13
4.1.2 show mirror.....	13
Chapter 5 MAC Configuration.....	15
5.1 MAC Address Configuration Commands.....	15
5.1.1 mac address-table static	15
5.1.2 mac address-table aging-time	15
5.1.3 show mac address-table	16
5.1.4 clear mac address-table	17
Chapter 6 Layer-2 (L2) Tunnel Protocol Configuration.....	18
6.1 L2 Channel Configuration Commands	18
6.1.1 l2protocol-tunnel.....	18
6.2 L2 Tunnel Monitoring Commands.....	18
6.2.1 debug l2 l2protocol-tunnel.....	18
Chapter 7 VLAN Configuration Commands.....	20
7.1 VLAN Configuration Commands	20
7.1.1 vlan.....	20
7.1.2 name	21

7.1.3 switchport pvid.....	21
7.1.4 switchport mode	22
7.1.5 switchport trunk.....	23
7.1.6 show vlan	23
Chapter 8 STP Configuration Commands	26
8.1 SSTP Configuration Commands	26
8.1.1 spanning-tree	26
8.1.2 spanning-tree mode	26
8.1.3 spanning-tree sstp priority	27
8.1.4 spanning-tree sstp hello-time	28
8.1.5 spanning-tree sstp max-age	28
8.1.6 spanning-tree sstp forward-time.....	29
8.1.7 spanning-tree sstp cost	30
8.1.8 spanning-tree cost.....	30
8.1.9 spanning-tree sstp port-priority.....	31
8.1.10 spanning-tree port-priority	32
8.1.11 show spanning-tree	33
8.1.12 spanning-tree management trap	34
8.2 VLAN STP Configuration Commands	34
8.2.1 spanning-tree mode pvst.....	34
8.2.2 spanning-tree vlan.....	35
8.2.3 spanning-tree vlan priority	36
8.2.4 spanning-tree vlan forward-time.....	36
8.2.5 spanning-tree vlan max-age	37
8.2.6 spanning-tree vlan hello-time	38
8.2.7 spanning-tree vlan cost	39
8.2.8 spanning-tree vlan port-priority.....	39
8.2.9 show spanning-tree vlan	40
8.3 RSTP Configuration Commands	41
8.3.1 spanning-tree mode rstp	41
8.3.2 spanning-tree rstp forward-time	42
8.3.3 spanning-tree rstp hello-time.....	42
8.3.4 spanning-tree rstp max-age	43
8.3.5 spanning-tree rstp priority.....	44
8.3.6 spanning-tree rstp cost.....	44
8.3.7 spanning-tree rstp port-priority	45
8.3.8 spanning-tree rstp edge	46
8.3.9 spanning-tree rstp point-to-point	46
8.3.10 spanning-tree rstp migration-check.....	47
8.4 MSTP Configuration Commands.....	48
8.4.1 spanning-tree mode mstp.....	48
8.4.2 spanning-tree mstp name.....	48
8.4.3 spanning-tree mstp revision	49
8.4.4 spanning-tree mstp instance	49
8.4.5 spanning-tree mstp root	50
8.4.6 spanning-tree mstp priority.....	51

8.4.7 spanning-tree mstp hello-time	52
8.4.8 spanning-tree mstp forward-time	53
8.4.9 spanning-tree mstp max-age	53
8.4.10 spanning-tree mstp diameter	54
8.4.11 spanning-tree mstp max-hops	54
8.4.12 spanning-tree mstp port-priority	55
8.4.13 spanning-tree mstp cost	56
8.4.14 spanning-tree mstp edge	56
8.4.15 spanning-tree mstp point-to-point	57
8.4.16 spanning-tree mstp mst-compatible	58
8.4.17 spanning-tree mstp migration-check	58
8.4.18 show spanning-tree mstp	59
8.4.19 show spanning-tree mstp region	60
8.4.20 show spanning-tree mstp detail	61
8.4.21 show spanning-tree mstp interface	62
8.5 Optional STP Attribute Configuration Commands	64
8.5.1 spanning-tree portfast	64
8.5.2 spanning-tree bpduguard	65
8.5.3 spanning-tree bpdufilter	66
8.5.4 spanning-tree uplinkfast	66
8.5.5 spanning-tree backbonefast	67
8.5.6 spanning-tree guard	68
8.5.7 spanning-tree loopguard	68
8.5.8 spanning-tree fast-aging	69
8.5.9 spanning-tree fast-aging flush-fdb	70
Chapter 9 802.1x Configuration Commands	72
9.1 802.1x Configuration Commands	72
9.1.1 dot1x enable	72
9.1.2 dot1x port-control	73
9.1.3 dot1x multiple-hosts	74
9.1.4 dot1x default	75
9.1.5 dot1x max-req	75
9.1.6 dot1x reauth-max	76
9.1.7 dot1x re-authentication	76
9.1.8 dot1x timeout quiet-period	77
9.1.9 dot1x timeout re-authperiod	78
9.1.10 dot1x timeout tx-period	78
9.1.11 dot1x user-permit	79
9.1.12 dot1x authentication method	80
9.1.13 dot1x authen-type、dot1x authentication type	80
9.1.14 dot1x guest-vlan	81
9.1.15 dot1x guest-vlan id	82
9.1.16 aaa authentication dot1x	83
9.1.17 debug dot1x error	83
9.1.18 debug dot1x state	84
9.1.19 debug dot1x packet	84

Table of Contents

9.1.20 show dot1x 85

Chapter 1 Physical Feature Configuration Commands

1.1 Interface Configuration Commands

The following are interface configuration commands:

- speed
- duplex
- flow-control

1.1.1 speed

Syntax

speed {10 / 100 /1000 / auto }

no speed

To set the speed of the interface, ran **speed {10| 100 | 1000 | auto}**.

Parameter

Parameter	Description
10, 100,1000	Sets the speed of a port to 10M, 100M or 1000M.
auto	Sets the speed of the interface to auto .

Default value

The speed of the electrical interface is auto, the speed of the 100M optical interface is 100M and the speed of the 1000M optical interface is 1000M.

Description

This command is configured in layer-2 interface configuration mode.

Note:

The speed of the optical interface is fixed. For example, the speeds of GBIC and GE-FX are 1000m, while the speed of FE-FX is 100M. If the **speed** command for an optical interface has the **auto** parameter, the optical interface has the automatic negotiation function, or the optical interface is mandatory and cannot be negotiated.

Example

The following example shows how to set the speed of interface switchFastEthernet4/1 to 100M:

```
Router_config# interface switchFastEthernet4/1
Router_config_sfe4/1# speed 100
```

1.1.2 duplex

Syntax

duplex {auto / full / half }

no duplex

To set the duplex mode of an interface, run **duplex {auto | full | half}**.

Parameter

Parameter	Description
auto	Automatic negotiation
full	Full duplex
half	Half duplex

Default value

The electrical interface is in automatic negotiation mode , while the optical interface is in full duplex mode.

Description

This command is configured in layer-2 interface configuration mode.

Note:

The duplex mode of the optical interface is fixed, that is, the duplex mode of all optical interfaces is the full duplex mode.

Example

The following example shows how to set interface switchFastEthernet4/1 to the full duplex mode.

```
Router_config# interface switchFastEthernet4/1
Router_config_sfe4/1# duplex full
```

1.1.3 flow-control

Syntax

flow-control [on|off]

no flow-control

To configure flow control for an interface, run **flow-control{on | off}**.

Parameter

None

Default value

Disables the flow control function.

Description

This command is configured in layer-2 interface configuration mode.

Example

The following example shows that the flow control function of the port is disabled.

```
Router_config_sfe4/1# no flow-control
```

Chapter 2 Port Protection and Security

2.1 Port Protection Commands

Port protection configuration commands include:

- switchport protected

2.1.1 switchport protected

Syntax

[no] switchport protected

To configure port protection and realize layer-2 isolation on an port, run this command.

Parameter

None

Default value

Port protection is not enabled on the switching port by default.

Description

When port protection is enabled, this port is isolated from other switching ports on layer 2.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to enable port protection on port sfe4/2.

```
Router_config#int sfe4/2  
Router_config_sfe4/2#switchport protected
```

2.2 Port Security Commands

The port security commands include:

- switchport port-security bind mac
- switchport port-security bind ip
- switchport port-security block mac
- switchport port-security block ip
- switchport port-security static mac-address
- switchport port-security mode static
- switchport port-security mode dynamic
- switchport port-security dynamic maximum

2.2.1 switchport port-security bind mac

Syntax

[no] switchport port-security bind mac *mac-address*

To bind a MAC address to a security port, run this command.

Parameter

Parameter	Description
<i>mac-address</i>	Stands for the bound MAC address. Its format is H.H.H.

Default value

No MAC address is bound to a switching port by default.

Description

When a security port is bound to a MAC address, only those packets whose source MAC address is same to the bound MAC address can pass through this security port.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to bind an MAC address to port sfe4/2.

Router_config#int sfe4/2

Router_config_sfe4/2# switchport port-security bind mac 0000.0000.0001

2.2.2 switchport port-security bind ip

Syntax

[no] switchport port-security bind ip *ip-address*

[no] switchport port-security bind ip *ip-address* mac *mac-address*

To bind IP to a security port, run **[no] switchport port-security bind ip *ip-address***.

At the same time the security port will be bound to an IP address and a MAC address.

Parameter

Parameter	Description
<i>ip-address</i>	Stands for the bound IP address. Its format is A.B.C.D.
<i>mac-address</i>	Stands for the bound MAC address. Its format is H.H.H.

Default value

No IP address is bound to a switching port by default.

Description

When a security port is bound to an IP address, only those packets whose source IP address is same to the bound IP address can pass through this security port.

When a security port is bound to an IP address and a MAC address simultaneously, only those packets whose source IP/MAC address is same to the bound IP/MAC address can pass through this security port.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to bind an IP address to port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2# switchport port-security bind ip 192.2.2.1
Router_config_sfe4/2# switchport port-security bind ip 192.2.2.2 mac 0000.0000.0001
```

2.2.3 switchport port-security block mac**Syntax**

[no] switchport port-security block mac *mac-address*

To filter the MAC addresses on a security port, run this command.

Parameter

Parameter	Description
<i>mac-address</i>	Stands for the filtered MAC address. Its format is H.H.H.

Default value

No MAC address is filtered on a switching port by default.

Description

When MAC filtration is filtered on a security port, only those packets whose source MAC address is same to the configured MAC address will be filtered and won't get through this port.

Example

The following example shows how to set MAC filtration on port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2# switchport port-security block mac 0000.0000.0001
```

2.2.4 switchport port-security block ip

Syntax

[no] switchport port-security block ip *ip-address*

[no] switchport port-security block ip *ip-address* mac *mac-address*

To filter IP addresses on a security port, run **[no] switchport port-security block ip *ip-address***.

At the same time the security port will filter IP addresses and MAC addresses.

Parameter

Parameter	Description
<i>ip-address</i>	Stands for the IP address. Its format is A.B.C.D.
<i>mac-address</i>	Means a MAC address. Its format is H.H.H.

Default value

No IP address is filtered on a switching port by default.

Description

When IP filtration is filtered on a security port, only those packets whose source IP address is same to the configured IP address will be filtered and won't get through this port.

When IP filtration and MAC filtration are enabled on a security port, only those packets whose source IP/MAC addresses are same to the configured IP/MAC addresses will be filtered and won't get through this port.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to set IP filtration on port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2# switchport port-security block ip 192.2.2.1
Router_config_sfe4/2# switchport port-security block ip 192.2.2.2 mac 0000.0000.0001
```

2.2.5 switchport port-security static mac-address

Syntax

[no] switchport port-security static mac-address *mac-address-value*

To configure the static MAC address table on a security port, run this command.

Parameter

Parameter	Description

<i>mac-address-value</i>	Means an MAC address. Its format is H.H.H.
--------------------------	--

Default value

None

Description

After the static MAC address table of a security port is configured, the matched packets are allowed or forbidden to pass through this port according to the current security mode.

When this command is used along with **switchport port-security mode static accept**, only the packets whose source MAC addresses are in the static MAC address table can pass through the security port.

When this command is used along with **switchport port-security mode static reject**, only the packets whose source MAC addresses are in the static MAC address table are forbidden to pass through the security port.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to configure the static MAC address table of the security port on port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2# switchport port-security static mac-address 0000.0000.0001
Router_config_sfe4/2# switchport port-security static mac-address 0000.0000.0002
```

2.2.6 switchport port-security mode static

Syntax

[no] switchport port-security mode static {accept|reject}

To configure the static MAC table mode on a security port, run this command.

Parameter

Parameter	Description
accept	Means that the packet whose source MAC address is in the static MAC address table is allowed to pass through.
reject	Means that the packet whose source MAC address is in the static MAC address table is forbidden to pass through.

Default value

None

Description

This command is used to allow or forbid those packets whose source MAC addresses are in the static MAC table to pass through the security port.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to enable the Allow mode of the static MAC table on port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2#switchport port-security mode static accept
```

2.2.7 switchport port-security mode dynamic

Syntax

[no] switchport port-security mode dynamic

To configure the dynamic mode of a security port, run this command.

Parameter

None

Default value

None

Description

When the security port is set to the dynamic mode, the security port will learn a certain number of MAC addresses and then does not receive packets with other addresses. The maximum number of dynamic MAC addresses can be configured by **switchport port-security dynamic maximum**.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to configure the dynamic mode of security port on port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2#switchport protected
```

2.2.8 switchport port-security dynamic maximum

Syntax

[no] switchport port-security dynamic maximum *number*

To configure the maximum number of learnable MAC addresses in dynamic security-port mode, run this command.

Parameter

Parameter	Description
<i>number</i>	Means the maximum number of dynamic MAC addresses.

Default value

1.

Description

In the dynamic security port mode, this command can be used to set the maximum number of learnable MAC addresses.

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to enable the maximum number of dynamic MAC addresses on port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2#switchport port-security dynamic maximum 10
```

Chapter 3 Control of Port Block and Storm

3.1 Configuration Commands of Port Block

The following command is used for port block settings :

- switchport protected

3.1.1 switchport block

Syntax

[no] switchport block {unicast | multicast | broadcast}

To configure an port not to forward a designated type of packets, run **switchport block {unicast / multicast / broadcast}**.

Parameter

Parameter	Description
unicast	Means that the unknown unicast frame is not forwarded on a port.
multicast	Means that the multicast frame is not forwarded on the port.
broadcast	Means that the broadcast frame is not forwarded on the port.

Default value

All packets can be forwarded by default.

Description

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to not forward unknown unicast frames on port sfe4/2.

```
Router_config#int sfe4/2
Router_config_sfe4/2#switchport block unicast
```

3.2 Storm Control Command

The storm control command is:

- storm-control

3.2.1 storm-control

Syntax

[no] storm-control {broadcast | multicast | unicast} threshold *count*

To configure flow control for a port, run **storm-control {broadcast | multicast | unicast} threshold *count***.

Parameter

Parameter	Description
broadcast multicast unicast	Defines broadcast/multicast/unicast storm control.
<i>count</i>	Defines the flow percent of storm control on a port. That is, it defines the threshold flux of the storm.

Default value

The storm control function is disabled by default.

Description

This command is configured in layer-2 interface configuration mode.

Example

The following example shows how to set the control percentage of unicast frame storm on port sfe4/2 to 20:

```
Router_config#int sfe4/2
Router_config_sfe4/2# storm-control unicast threshold 20
```

Chapter 4 Port mirroring

4.1 Port Mirroring Configuration Commands

Port mirroring configuration commands include:

- mirror
- show mirror

4.1.1 mirror

Syntax

```
[no] mirror session session_number {destination {interface interface-id} | source {interface interface-id [, | -] [both | rx | tx]}}
```

To configure port mirroring, run **mirror session *session_number* {destination {interface *interface-id*} { rspan *vid tpid*} | source {interface *interface-id* [, | -] [rx | tx]} }.**

Parameter

Parameter	Description
<i>session_number</i>	Number of port mirroring Value range: 1
<i>destination</i>	Information about destination port mirroring
<i>source</i>	Information about the mirrored port
<i>both / rx / tx</i>	Data flow that will be mirrored rx means that only the input data is mirrored; tx means that only the output data is mirrored; both means both the input data and the output data are mirrored.

Default value

None

Description

This command is configured in global configuration mode.

Example

The following example shows how to set port sfe4/2 to the output mirror of port sfe4/1.

```
Router_config# mirror session 1 destination interface sfe4/2
Router_config# mirror session 1 source interface sfe4/1 tx
```

4.1.2 show mirror

Syntax

```
show mirror [session session_number]
```

To display the information about port mirroring, run **show mirror [session session_number]**.

Parameter

Parameter	Description
<i>session_number</i>	Number of port mirroring Value range: 1

Default value

None

Instruction

This command is used to display the information about port mirroring.

Example

The following example shows how to display the information about all port mirroring.

```
Switch# show mirror
Session 1
-----
Source Ports:
RX Only: Fe0/3
TX Only: None
Both: None
Source VLANs:
RX Only: None
TX Only: None
Both: None
```

Chapter 5 MAC Configuration

5.1 MAC Address Configuration Commands

5.1.1 mac address-table static

Syntax

[no] mac address-table static *mac-addr* vlan *vlan-id* interface *interface-id*

To add a static MAC address, run **mac address-table static *mac-addr* vlan *vlan-id* interface *interface-id***. To cancel the static MAC address, run **no mac address-table static *mac-addr* vlan *vlan-id* interface *interface-id***.

Parameter

Parameter	Description
<i>mac-addr</i>	Means an MAC address. Value range: H.H.H
<i>vlan-id</i>	A VLAN that the MAC address belongs to Value range: 1-4094
<i>interface-id</i>	Physical port that the MAC address belongs to

Default value

None

Instruction

This command is configured in global configuration mode.

Example

The following example shows how to bind MAC address 0004.5600.67ab to port sfe4/2 of VLAN1.

```
Router_config# mac address-table static 0004.5600.67ab vlan 1 interface sfe4/2
```

5.1.2 mac address-table aging-time

Syntax

mac address-table aging-time [0 | 10-1000000]

To configure the aging time of the MAC address table, run the previous command.

Parameter

Parameter	Description
0	Means that the MAC address never ages.
10-1000000	Aging time of the MAC address whose unit is second

Default value

None

Instruction

This command is configured in global configuration mode.

Example

The following example shows how to set the aging time of the MAC address to 100 seconds.

```
Router_config# mac address-table aging-time 100
```

5.1.3 show mac address-table**Syntax**

```
show mac address-table {dynamic [interface interface-id | vlan vlan-id] | static}
```

To display the MAC address table of the switch, run **show mac address-table {dynamic [interface *interface-id* | vlan *vlan-id*] | static}**.

Parameter

Parameter	Description
dynamic	Dynamically-learned MAC address table
<i>interface-id</i>	Name of an interface
<i>vlan-id</i>	Value range: 1-4094
static	Static MAC address table

Default value

None

Instruction

This command is used to display the MAC address table.

Example

The following example shows how to display all static MAC address tables.

```
Switch# show mac address-table static
Mac Address Table
```

```
-----
```

```
Vlan Mac Address Type Ports
```

```
-----
```

All 0000.0000.0001 STATIC CPU
All 0000.0000.0002 STATIC CPU
All 0000.0000.0003 STATIC CPU
All 0000.0000.0009 STATIC CPU

```

All 0000.0000.0012 STATIC CPU
All 0180.c200.000b STATIC CPU
All 0180.c200.000c STATIC CPU
All 0180.c200.000d STATIC CPU
All 0180.c200.0010 STATIC CPU

```

5.1.4 clear mac address-table

Syntax

```
clear mac address-table dynamic [address mac-addr | interface interface-id | vlan vlan-id]
```

To delete a dynamic MAC address, run the previous command.

Parameter

Parameter	Description
<i>dynamic</i>	Means a dynamic MAC address.
<i>address mac-addr</i>	Means an MAC address. Value range: H.H.H
<i>interface-id</i>	Means a name of a L2 interface.
<i>vlan-id</i>	VLAN ID. Value range: 1-4094

Default value

None

Description

This command is used in EXEC mode.

Example

The following example shows how to clear all dynamically-learned MAC addresses on interface sfe4/2.

```
Switch# clear mac address-table dynamic interface sfe4/2
```

Chapter 6 Layer-2 (L2) Tunnel Protocol Configuration

6.1 L2 Channel Configuration Commands

The following is a L2 tunnel monitoring command:

- l2protocol-tunnel

6.1.1 l2protocol-tunnel

Syntax

[no] l2protocol-tunnel [stp]

To configure the layer-2 (L2) protocol tunnel, run the previous command.

Parameter

None

Default value

By default, the tunnel function of any L2 protocol is not enabled on the port of the switch.

When the tunnel function is enabled, the tunnel function of all supported L2 protocols is enabled if no specific L2 protocol is designated.

Description

Currently only STP supports the tunnel function in our switches.

Example

The following example shows how to enable the tunnel function of the STP (including STP/PVST) on interface **switchFastEthernet 4/1**.

```
Router_config#int switchFastEthernet 4/1
Router_config_sfe4/1#l2protocol-tunnel stp
```

6.2 L2 Tunnel Monitoring Commands

The following is a L2 tunnel monitoring command:

- debug l2 l2protocol-tunnel

6.2.1 debug l2 l2protocol-tunnel

Syntax

[no] debug l2 l2protocol-tunnel [error | packet]

To set the debugging option of the L2 protocol tunnel, run the previous command.

Parameter

None

Default value

If a specific option is not designated, all debugging options of a L2 protocol tunnel are enabled by default.

Description

None

Example

The following example shows how to enable the tunnel function of the STP on interface f0/2.

```
Router_config#int f0/2  
Router_config_f0/2#l2protocol-tunnel stp
```

Chapter 7 VLAN Configuration Commands

7.1 VLAN Configuration Commands

The following are VLAN configuration commands:

- `vlan`
- `name`
- `vlan access-map`
- `action`
- `match`
- `vlan filter`
- `switchport pvid`
- `switchport mode`
- `switchport trunk`
- `switchport trunk`

7.1.1 `vlan`

[no] `vlan` *vlan-id*

To add or delete VLAN, run `vlan vlan-id` or `no vlan vlan-id`.

Parameter

Parameter	Description
<code>vlan-id</code>	Defines the ID of the VLAN. Value range: 1-4094

Default value

None

Command mode

Global configuration mode

Instruction

After this command is run, the system enters the VLAN configuration mode and then you can modify some VLAN attributes.

Example

The following example shows how to add the VLAN whose ID is 200:

```
Router_config#
Router_config#vlan 2
Router_config_vlan_2#
```

7.1.2 name

[no] name str

To name a VLAN, run **name str**.

Parameter

Parameter	Description
<i>str</i>	Defines the name of the VLAN. Value range: 1-32 characters

Default value

The name of the default VLAN is **default**. Other VLANs are named as VLANxxxx (xxxx stands for a 4-bit ID).

Command mode

VLAN configuration mode

Instruction

This command can be used to modify the VLAN name to symbolize a specific VLAN.

Example

The following example shows how to set the name of VLAN200 to **main405**:

```
Router_config#
Router_config#
Router_config#vlan 200
Router_config_vlan_200#name ?
      WORD  The ascii name of VLAN(32bytes)
Router_config_vlan_200#name main405
```

7.1.3 switchport pvid

switchport pvid *vlan-id*

no switchport pvid

To configure VLAN of the access-mode port, run **switchport pvid *vlan-id***.

Parameter

Parameter	Description
<i>vlan-id</i>	VLAN ID which the port belongs to, ranging between 1 and 4094 Value range: 1-4094

Default value

All ports belong to VLAN 1.

Command mode

Port configuration mode

Instruction

Before this command is configured, VLAN which PVID belongs to must exist. The port can be in access mode or relay mode.

Example

The following example shows how to set port **switchFastEthernet 4/1** to the access port of VLAN10:

```
Router_config#vlan10
Router_config#interface switchFastEthernet 4/1
Router_config_sfe4/1#switchport pvid 10
```

7.1.4 switchport mode

```
switchport mode {access | trunk | dot1q-tunnel tpid | dot1q-tunnel-uplink tpid |
dot1q-translating-tunnel}
no switchport mode
```

To configure the mode of the port, run the previous command.

Parameter

Parameter	Description
<i>access</i>	Access mode
<i>trunk</i>	Relay mode

Default value

Access mode

Command mode

Port configuration mode

Instruction

The switch's port supports the following two modes: access mode and relay mode.

The access mode indicates that the port belongs to just one VLAN; only the untagged Ethernet frame can be transmitted and received.

The relay mode indicates that the port connects other switches and the tagged Ethernet frame can be transmitted and received.

The 802.1X standard does not support authentication on the trunk port. The reason is that the authentication object regulated in the standard is not the port. As to port multiplexing, if user authentication is approved in one VLAN, all other VLAN users who multiplex this port are also authorized correspondingly, therefore, the trunk port does not support authentication.

7.1.5 switchport trunk

[no] switchport trunk {*vlan-allowed vlan-list*} | {*vlan-untagged vlan-list*}

To configure the attributes of the relay port, run the previous command.

Parameter

Parameter	Description
<i>vlan-allowed</i>	VLAN ID which can be received and transmitted by the port Value range: 1-4094
<i>vlan-untagged</i>	Frame that will be transmitted without adding the VLAN tag Value range: 1-4094

Default value

The native VLAN ID of all relay ports is 1. The allowable value for all VLANs ranges between 1 and 4094.

Command mode

Port configuration mode

Instruction

No matter the port is in access mode or in relay mode, you can run this command on the port. However, the port is in relay mode when this command functions.

The **vlan-allowed** parameter is used to control the VLAN range of the port; the **vlan-untagged** parameter is used to control the transmission of the untagged VLAN packets from the port.

When the *vlan* list is used, you can add, remove or set the lists of the existing VLAN. The entered lists are separated by the comma or the hyphen. For example, "1, 3, 5, 7" stands for "vlan 1, vlan 3, vlan 5, vlan 7", while "1, 3-5, 7" stands for "vlan 1, vlan 3, vlan 4, vlan 5, vlan 7".

Example

The following example shows how to set the allowed VLAN range to 1-10.

```
Router_config_sfe4/1#switchport trunk vlan-allowed 1-10,20-30,55
Router_config_sfe4/1#switchport trunk vlan-untagged 2-1000
```

7.1.6 show vlan

show vlan [access-map | filter | id *vlan-id* | interface *intf-id* | dot1q-tunnel [interface *intf*]]

To display relative information about all VLANs, run the previous command.

Parameter

Parameter	Description

access-map	Displays all VLAN access lists.
filter	Displays all VLAN filters.
<i>id</i>	Displays the designated VLAN. Value range: 1-4094
<i>interface</i>	Displays the designated port.
dot1q-tunnel [interface int]	Displays the global information and statistics information about Dot1Q tunnel, or displays the detailed information about Dot1Q tunnel of the designated port.

Default value

None

Command mode

EXEC mode

Instruction

None

Example

The following example shows how to display relative information about all VLANs.

```
Switch#sho vlan
VLAN Status Name          Ports
-----
1   Static Default        F0/1, F0/2, F0/3, F0/4, F0/5, F0/6, F0/7, F0/8
                           F0/9, F0/10, F0/11, F0/12, F0/13, F0/14, F0/15
                           F0/16, F0/17, F0/18, F0/19, F0/20, F0/21, F0/22
                           F0/23, F0/24, G1/1, G2/1, P1
2   Static VLAN0002       F0/3
3   Static VLAN0003       F0/3
4   Static VLAN0004       F0/3
5   Static VLAN0005       F0/3
6   Static VLAN0006       F0/3
```

The **status** parameter stands for the VLAN generation source; the **static** parameter means that VLAN is generated through configuration; the **dynamic** parameter means that VLAN is generated dynamically through the GVRP protocol.

The following example shows the detailed information about a VLAN:

```
Switch> show vlan id 1
VLAN id: 1, Name: default, TotalPorts:11
```

Ports	Attributes
F0/1	Trunk,Untagged
F0/2	Access
F0/5	Trunk,Untagged
F0/7	Trunk,Tagged
F0/8	Trunk,Tagged

F0/9	Trunk,Tagged
F0/11	Access
F0/12	Access
F0/14	Trunk,Tagged
F0/15	Trunk,Tagged
F0/16	Trunk,Untagged

The following example shows relative information about a VLAN on a port:

```
Switch#sho vlan int f0/6
```

Interface	VLAN	
Name	Property PVID Vlan-Map	uTagg-VLan-Map
FastEthernet0/6	Trunk 1 3,5,7,9,11,13,15 none 17,19	

```
Switch#sho vlan int f0/7
```

Interface	VLAN	
Name	Property PVID Vlan-Map	uTagg-VLan-Map
FastEthernet0/7	Access 7 7	---

The following example shows how to display the VLAN access table:

```
Switch#show vlan access-map
```

```
Vlan access-map "map_1" 10
```

Match clauses:

ip address: ip1

Action:

drop

```
Vlan access-map "map_1" 20
```

Match clauses:

mac address: mac1

Action:

forward

```
Vlan access-map "map_1" 30
```

Match clauses:

Action:

Drop

The following example shows how to display the VLAN filtration list:

```
Switch#show vlan filter
```

```
VLAN Map map_1 is filtering VLANs:
```

20-22

Chapter 8 STP Configuration Commands

8.1 SSTP Configuration Commands

8.1.1 spanning-tree

Syntax

```
spanning-tree
no spanning-tree
```

To enable the default STP mode, run **spanning-tree**; to disable the STP, run **no spanning-tree**.

Parameter

None

Default value

RSTP is enabled by default.

Instruction

None

Command mode

Global configuration mode

Physical interface configuration mode or aggregation port configuration mode

Example

None

8.1.2 spanning-tree mode

Syntax

```
spanning-tree mode {rstp|sstp}
no spanning-tree mode
```

To configure the spanning-tree operation mode, run **spanning-tree mode {rstp|sstp}**.
To forbid STP running, run **no spanning-tree mode**.

Parameter

Parameter	Description
rstp	Starts the RSTP mode.

sstp	Starts the SSTP mode.
-------------	-----------------------

Default value

SSTP 或 RSTP

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to enable the SSTP mode.

```
Router_config# spanning-tree mode sstp
Router_config#
```

8.1.3 spanning-tree sstp priority**Syntax**

(1) **spanning-tree sstp priority *value***
no spanning-tree sstp priority

To configure the SSTP priority value, run **spanning-tree sstp priority *value***. To resume the default value of the SSTP priority value, run **no spanning-tree sstp priority**.

Parameter

Parameter	Description
<i>value</i>	Priority value Value range: 0-61440

Default value

32768

Description

When setting the priority value, you can make the switch as the root of the whole network spanning tree. The configuration value takes 4096 as a step and its value is the multiple of 4096. The configurable values are 0, 4096, 8192, 3*4096, 4*4096,..... and 15*4096.

Command mode

Global configuration mode

Example

The following example shows how to set the priority level of Sstp to 4096.

```
Router_config# spanning-tree sstp priority 4096
Router_config#
```

8.1.4 spanning-tree sstp hello-time

Syntax

spanning-tree sstp hello-time *time*

no spanning-tree sstp hello-time

To configure the transmission interval of Sstp packets, run **spanning-tree sstp hello-time *time***. To resume the default transmission interval, run **no spanning-tree sstp hello-time**.

Parameter

Parameter	Description
<i>time</i>	Updates the interval. Range: 1-10 seconds

Default value

4s

Instruction

The Hello-Time configured on the local switch validates only when the local switch runs as a root switch.

Command mode

Global configuration mode

Example

The following example shows how to configure the transmission interval of BPDU of Sstp to 8 seconds.

```
Router_config# spanning-tree sstp hello-time 8
Router_config#
```

8.1.5 spanning-tree sstp max-age

Syntax

spanning-tree sstp max-age *time*

no spanning-tree sstp max-age

To configure the maximum lifespan of the Sstp BPDU, run **spanning-tree sstp max-age *time***. To resume the default interval time, run **no spanning-tree sstp max-age**.

Parameter

Parameter	Description
<code>seconds</code>	Means the maximum lifespan of BPDU. Range: 6-40 seconds

Default value

20s

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to configure the maximum lifespan of Sstp to 24 seconds.

```
Router_config# spanning-tree sstp max-age 24
Router_config#
```

8.1.6 spanning-tree sstp forward-time**Syntax**

spanning-tree sstp forward-time *time*

no spanning-tree sstp forward-time

To configure the forwarding delay, run **spanning-tree sstp forward-time *time***. To resume the default forwarding delay, run **no spanning-tree sstp forward-time**.

Parameter

Parameter	Description
<code>time</code>	Time of the forwarding delay Value range: 4-30 seconds

Default value

15 seconds

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to configure the forwarding delay of SSTP to 20 seconds.

```
Router_config# spanning-tree sstp forward-delay 20
Router_config#
```

8.1.7 spanning-tree sstp cost

Syntax

spanning-tree sstp cost *value*

no spanning-tree sstp cost

To configure the path cost of a port in SSTP mode, run **spanning-tree sstp cost *value***. To resume the default path cost, run **no spanning-tree sstp cost**.

Parameter

Parameter	Description
<i>value</i>	Value of the path cost Value range: 1-200000000

Default value

The value of the path cost of the 10M Ethernet is 100.

+The value of the path cost of the 100M Ethernet is 19.

The value of the path cost of the 1000M Ethernet is 1.

Instruction

None

Command mode

Port configuration mode

Example

The following example shows how to set the path cost of port **switchFastEthernet 4/1** to 100 in SSTP mode.

```
Router_config_sfe4/1#spanning-tree sstp cost 100
Router_config_sfe4/1#
```

8.1.8 spanning-tree cost

Syntax

spanning-tree cost *value*

no spanning-tree cost

To configure the path cost of a port in all STP mode, run **spanning-tree cost value**. To resume the default path cost, run **no spanning-tree cost**.

Parameter

Parameter	Description
<i>value</i>	Value of the path cost of a port Value range: 1-200000000

Default value

The default value depends on the rate of each port in all STP mode.

Instruction

The results of this command validates in all STP modes. In VLAN-based STP mode, the path cost of a port will be updated in all VLAN spanning trees; In MSTP mode, the path cost of a port will be updated in all STP cases.

However, the results of this command cannot affect independent configurations in each mode. For example, After you run **spanning-tree sstp cost 100** and **spanning-tree cost 110**, the path cost of the port is still 100 in Sstp mode.

Command mode

Port configuration mode

Example

The following example shows how to set the path cost of port **switchFastEthernet 4/1** to 24:

```
Router_config_sfe4/1# spanning-tree cost 24
Router_config_sfe4/1#
```

8.1.9 spanning-tree sstp port-priority

Syntax

spanning-tree sstp port-priority value

no spanning-tree sstp port-priority

To configure the priority value of a port in Sstp mode, run **spanning-tree sstp port-priority value**. To resume the default value of the priority value, run **no spanning-tree sstp port-priority**.

Parameter

Parameter	Description
<i>value</i>	Priority level of a port Value range: 0-255

Default value

128 (0x80)

Instruction

The value of the priority level of a port must be the multiple of 16.

Command mode

Port configuration mode

Example

The following example shows how to set the priority level of port **switchFastEthernet 4/1** to 32:

```
Router_config_sfe4/1# spanning-tree sstp port-priority 32
Router_config_sfe4/1#
```

8.1.10 spanning-tree port-priority**Syntax**

spanning-tree port-priority value

no spanning-tree port-priority

To configure the priority level of a port in all STP modes, run **spanning-tree port-priority value. To resume the default priority level, run **spanning-tree port-priority**.**

Parameter

Parameter	Description
value	Means the priority level of a port. Value range: 0-255 Step: 16

Default value

The default value of the priority level of a port is 128 in all modes.

Instruction

The results of this command validates in all STP modes. In VLAN-based STP mode, the priority level of a port will be updated in all VLAN spanning trees; In MSTP mode, the priority level of a port will be updated in all STP cases.

However, the results of this command cannot affect independent configurations in each mode. For example, After you run **spanning-tree sstp port-priority 100** and **spanning-tree port-priority 110**, the port-priority of the port is still 100 in Sstp mode.

Command mode

Port configuration mode

Example

The following example shows how to set the priority level of port switchFastEthernet 4/1 to 16 in all STP modes.

```
Router_config_sfe4/1#spanning-tree port-priority 16
Router_config_sfe4/1#
```

8.1.11 show spanning-tree

Syntax

show spanning-tree [detail | interface *intf-i*]

To display the spanning-tree information, run the previous command.

Parameter

Parameter	Description
<i>intf-i</i>	Name of the port, such as F0/10 and G1/1

Default value

None

Description

This command is used to display the state of the spanning tree.

Command mode

Port configuration mode

Example

```
Router_config#show span
```

Spanning tree enabled protocol SSTP

SSTP

Root ID This bridge is the root

Bridge ID	Priority	32768
	Address	00E0.0F64.8365
	Hello/MaxAge/FwdDly	4/20/15(s)

Intf Name	Port ID Pri.Nbr Role Sts Cost	Designated Bridge ID	Port ID Pri.Nbr Cost
F0/47	128.47 Desg LIS 12	32768 00E0.0F64.8365	128.47 0

```
Router_config#
```

8.1.12 spanning-tree management trap

Syntax

spanning-tree management trap [newroot | topologychange]

To enable STP Trap, run the above-mentioned command.

Parameter

Parameter	Description
newroot	Stands for the newRoot trap type.
topologychange	Stands for the topologyChange trap type.

Default value

None

Description

This command is used to enable STP Trap.

Command mode

Global configuration mode

Example

None

8.2 VLAN STP Configuration Commands

Note:

S2116, S2448, S3448, S6508 and S8500 support the modes in which the spanning tree cases are based on VLAN. Please refer to related device models and corresponding software version documents.

8.2.1 spanning-tree mode pvst

Syntax

spanning-tree mode pvst

no spanning-tree mode

To enable VLAN-based STP mode, run **spanning-tree mode pvst**. To disable all STP modes, run **no spanning-tree mode**.

Parameter

None

Default value

The default STP mode is SSTP or RSTP.

Instruction

None

Example

The following example shows how to enable PVST on the switch.

```
Router_config# spanning-tree mode pvst
Router_config#
```

8.2.2 spanning-tree vlan

Syntax

```
spanning-tree vlan vlan-list
no spanning-tree vlan vlan-list
```

To designate VLAN to distribute the STP case, run **spanning-tree vlan *vlan-list***. To cancel the spanning tree of the designated VLAN, run **no spanning-tree vlan *vlan-list***.

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15

Default value

By default, the switch creates the first 30 VLAN STP cases.

Other VLANs are automatically added to the STP forbidden list.

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to cancel the spanning tree of VLAN 10, 11, 15-19 and then how to distribute the spanning trees to VLAN 40-50.

```
Router_config#no spanning-tree vlan 10,11,15-19
Router_config#spanning-tree vlan 40-50
Router_config#
```

8.2.3 spanning-tree vlan priority

Syntax

spanning-tree vlan *vlan-list* priority *value*

no spanning-tree vlan *vlan-list* priority

To designate the priority level of the bridge of the VLAN STP, run **spanning-tree vlan *vlan-list* priority *value***.

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15
<i>value</i>	Value of the priority level, ranging between 0 and 61400 (step: 4096)

Default value

By default, the priority level of the bridge of each VLAN spanning tree is 32768 plus the VLAN number.

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to set the priority levels of the bridges of VLAN1-3, 5-10 to 4096.

```
Router_config#spanning-tree vlan 1-3,5-10 priority 4096
Router_config#
```

8.2.4 spanning-tree vlan forward-time

Syntax

spanning-tree vlan *vlan-list* forward-time *value*

no spanning-tree vlan *vlan-list* forward-time

To set the Forward Delay parameter of the spanning tree in the designated VLAN, run **spanning-tree vlan *vlan-list* forward-time *value***.

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15

<i>value</i>	Value of the forward-delay parameter Value range: 4-30 seconds Default value: 15 seconds
--------------	--

Default value

The value of the **forward-delay** parameter of all VLANs is 15 seconds.

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to set the **forward delay** parameter of VLAN 1-3, 5-10 to 19 seconds.

```
Router_config#spanning-tree vlan 1-3,5-10 forward-time 19
Router_config
```

8.2.5 spanning-tree vlan max-age**Syntax**

spanning-tree vlan *vlan-list max-age value*

no spanning-tree vlan *vlan-list max-age*

To set the **Max Age** parameter of the spanning tree in the designated VLAN, run **spanning-tree vlan *vlan-list max age value***. To resume the default value, run **no spanning-tree vlan *vlan-list max age***.

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15
<i>value</i>	Value of the max-age parameter Value range: 6-40 seconds Default value: 20 seconds

Default value

The default value of the **max-age** parameter for all VLANs is 20 seconds.

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to set the **max age** parameter of VLAN 1-3, 5-10 to 19 seconds.

```
Router_config#spanning-tree vlan 1-3,5-10 max-age 19
Router_config
```

8.2.6 spanning-tree vlan hello-time

Syntax

```
spanning-tree vlan vlan-list hello-time value
no spanning-tree vlan vlan-list hello-time
```

To set the **hello time** parameter of the spanning tree in the designated VLAN, run **spanning-tree vlan** *vlan-list* **hello time** *value*. To resume the default value, run **no spanning-tree vlan** *vlan-list* **hello time**.

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15
<i>value</i>	Value of the hello time parameter Value range: 1-10 seconds Default value: 4 seconds

Default value

The default value of the **Hello-Time** parameter for all VLANs is 4 seconds.

Instruction

None

Command mode

Global configuration mode

Example

The following example shows how to set the **Hello Time** parameter of VLAN 1-3, 5-10 to 9 seconds.

```
Router_config#spanning-tree vlan 1-3,5-10 hello-time 9
Router_config
```

8.2.7 spanning-tree vlan cost

Syntax

spanning-tree vlan *vlan-list* cost *value*

no spanning-tree vlan *vlan-list* cost

To set the path cost of the spanning tree in the designated VLAN, run **spanning-tree vlan *vlan-list* cost *value***. To resume the default value, run **no spanning-tree vlan *vlan-list* cost**.

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15
<i>value</i>	Path cost of a port, which ranges between 1 and 200,000,000

Default value

The path cost of a port depends on the port rate.

The value of the path cost of the 10M Ethernet is 100.

+The value of the path cost of the 100M Ethernet is 19.

The value of the path cost of the 1000M Ethernet is 1.

Instruction

None

Command mode

Port configuration mode

Example

The following example shows how to set the path cost of port switchFastEthernet 4/10 VLANs 1, 2, 3, 5, 6, 7, 8, 9, 10 to 100.

```
Router_config_sfe4/10)#spanning-tree vlan 1-3,5-10 cost 100
Router_config_sfe4/10)
```

8.2.8 spanning-tree vlan port-priority

Syntax

spanning-tree vlan *vlan-list* port-priority *value*

no spanning-tree vlan *vlan-list* port-priority

To set the priority level of the spanning tree in the designated VLAN, run **spanning-tree vlan *vlan-list* port-priority *value***. To resume the default value, run **no spanning-tree vlan *vlan-list* port-priority**.

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15
<i>value</i>	Priority level of a port, which ranges between 0 and 255 and whose step is 16

Default value

128

Instruction

None

Command mode

Port configuration mode

Example

The following example shows how to set the priority level of port switchFastEthernet 4/1 VLAN1-3,5-10 to 32.

```
Router_config_sfe4/1#spanning-tree vlan 1-3,5-10 port-priority 32
```

8.2.9 show spanning-tree vlan

Syntax

show spanning-tree vlan *vlan-list* [*detail*]

To check the state of the spanning tree in the designated VLAN, run the previous command:

Parameter

Parameter	Description
<i>vlan-list</i>	List of the VLAN numbers, such as 1,2,3-10,15
<i>detail</i>	Displays the detailed information about the state of the spanning tree.

Default value

None

Instruction

None

Command mode

None

Example

The following example shows how to check the spanning tree of VLAN 1-2.

```
Router_config#show spanning-tree vlan 1-2
```

Spanning tree enabled protocol PVST

VLAN0001

Root ID	This bridge is the root
---------	-------------------------

Bridge ID	Priority	4097
	Address	00E0.0F64.8365
	Hello/MaxAge/FwdDly	4/20/15(s)

Intf	Port ID	Designated	Port ID
Name	Pri.Nbr Role Sts Cost	Bridge ID	Pri.Nbr Cost
F0/47	128.47 Desg FWD 12	4097 00E0.0F64.8365	128.47 0

VLAN0002

Root ID	This bridge is the root
---------	-------------------------

Bridge ID	Priority	4098
	Address	00E0.0F64.8365
	Hello/MaxAge/FwdDly	4/20/15(s)

Intf	Port ID	Designated	Port ID
Name	Pri.Nbr Role Sts Cost	Bridge ID	Pri.Nbr Cost
F0/47	128.47 Desg FWD 12	4098 00E0.0F64.8365	128.47 0

```
Router_config#
```

8.3 RSTP Configuration Commands

8.3.1 spanning-tree mode rstp

Syntax

spanning-tree mode rstp

no spanning-tree mode

To enable the RSTP function, run **spanning-tree mode rstp**. To disable the STP, run **no spanning-tree mode**.

Parameter

None

Default value

RSTP is running.

Instruction

None

Example

The following example shows how to enable RSTP on the switch.

```
Router_config# spanning-tree mode rstp
Router_config#
```

8.3.2 spanning-tree rstp forward-time**Syntax**

spanning-tree rstp forward-time *time*

no spanning-tree rstp forward-time

To configure the forwarding delay of RSTP, run **spanning-tree rstp forward-time *time***. To resume the default forwarding delay of RSTP, run **no spanning-tree rstp forward-time**.

Parameter

Parameter	Description
<i>time</i>	Time of the forwarding delay Range: 4-30 seconds

Default value

15 seconds

Instruction

None

Example

The following example shows how to set the forwarding delay of RSTP to 20 seconds.

```
Router_config# spanning-tree rstp forward-time 20
Router_config#
```

8.3.3 spanning-tree rstp hello-time**Syntax**

spanning-tree rstp hello-time *time*

no spanning-tree rstp hello-time

To configure the update interval of RSTP, run **spanning-tree rstp hello-time *time***. To resume the default update interval of RSTP, run **no spanning-tree rstp hello-time**.

Parameter

Parameter	Description
<i>time</i>	Updates the interval. Range: 1-10 seconds

Default value

4 seconds

Instruction

The Hello-Time configured on the local switch validates only when the local switch runs as a root switch.

Example

The following example shows how to set the update interval of RSTP to 8 seconds.

```
Router_config# spanning-tree rstp hello-time 8
Router_config#
```

8.3.4 spanning-tree rstp max-age

Syntax

spanning-tree rstp max-age *time*

no spanning-tree rstp max-age

To configure the maximum lifespan of the RSTP BPDU, run **spanning-tree rstp max-age *time***. To resume the default interval time, run **no spanning-tree rstp max-age**.

Parameter

Parameter	Description
<i>time</i>	Maximum interval of the lifespan Range: 6-40 seconds

Default value

20 seconds

Instruction

None

Example

The following example shows how to set the maximum lifespan of RSTP to 24 seconds.

```
Router_config# spanning-tree rstp max-age 24
Router_config#
```

8.3.5 spanning-tree rstp priority

Syntax

spanning-tree rstp priority value

no spanning-tree rstp priority

To configure the RSTP priority value, run **spanning-tree rstp priority value**. To resume the default value of the RSTP priority value, run **no spanning-tree rstp priority**.

Parameter

Parameter	Description
<i>value</i>	Priority level of the bridge Value range: 0-61440 Step: 4096

Default value

32768

Instruction

None

Example

The following example shows how to set the bridge priority of RSTP to 4096.

```
Router_config# spanning-tree rstp priority 4096
Router_config#
```

8.3.6 spanning-tree rstp cost

Syntax

spanning-tree rstp cost value

no spanning-tree rstp cost

To configure the path cost of a port, run **spanning-tree rstp cost value**. To resume the default value, run **no spanning-tree rstp cost**.

Parameter

Parameter	Description

<i>value</i>	Value of the path cost Value range: 1-200000000
--------------	---

Default value

The path cost depends on the connection rate of the port.

10 Mbps: 2000000

100 Mbps: 200000

1000 Mbps: 20000

Instruction

None

Example

The following example shows how to set the path cost of port **switchFastEthernet 4/1** to 24:

```
Router_config_sfe4/1# spanning-tree rstp cost 24
```

8.3.7 spanning-tree rstp port-priority**Syntax**

spanning-tree rstp port-priority *value*

no spanning-tree rstp port-priority

To configure the priority level of a port, run **spanning-tree rstp port-priority** *value*. To resume the default value, run **no spanning-tree rstp port-priority**.

Parameter

Parameter	Description
<i>value</i>	Priority level of a port Value range: 0-255 Step: 16

Default value

128

Instruction

None

Example

The following example shows how to set the priority level of port switchFastEthernet 4/1 to 24:

```
switch(config_f0/0)# spanning-tree rstp port-priority 24
switch(config_f0/0)#

```

8.3.8 spanning-tree rstp edge

Syntax

spanning-tree rstp edge [force-true | force-false | auto]

To set the edge of a port to **force-true**, **force-false** or **auto**, run this command.

Parameter

Parameter	Description
<i>force-true</i>	Sets the edge port to be forcedly effective.
<i>force-false</i>	Sets the edge port to be forcedly ineffective.
<i>auto</i>	Sets the edge port to be automatic check (default).

Default value

None

Instruction

This command is used only in switches that support IEEE 802.1D 2004 RSTP.

Command mode

Port configuration mode

Example

None

8.3.9 spanning-tree rstp point-to-point

Syntax

spanning-tree rstp point-to-point [force-true | force-false | auto]

To set the point-to-point connection of a port to **force-true**, **force-false** or **auto**, run this command.

Parameter

Parameter	Description
<i>force-true</i>	Sets the point-to-point connection to be forcedly effective.
<i>force-false</i>	Sets the point-to-point connection to be forcedly ineffective.
<i>auto</i>	Sets the point-to-point connection to be automatic check (default).

Default value

None

Instruction

This command is used only in switches that support IEEE 802.1D 2004 RSTP.

Command mode

Port configuration mode

Example

None

8.3.10 spanning-tree rstp migration-check

Syntax

spanning-tree rstp migration-check

To restart checking protocol transfer of RSTP, run the previous command.

Parameter

None

Default value

None

Instruction

This command is used to restart the protocol transfer check on a port and to change the port in STP-compatible mode to the RSTP mode, enabling RSTP BPDU to be transmitted.

This command is used only in switches that support IEEE 802.1D 2004 RSTP.

Command mode

Global or port configuration mode

Example

The following example shows how to check protocol transfer on port switchFastEthernet 4/10.

```
Router_config_sfe4/10)#spanning-tree rstp migration-check  
Router_config_sfe4/10)
```

8.4 MSTP Configuration Commands

8.4.1 spanning-tree mode mstp

Syntax

spanning-tree mode mstp

no spanning-tree mode

To set the operation mode of the spanning tree to MSTP, run **spanning-tree mode mstp**. To stop running STP, run **no spanning-tree mode**.

Parameter

None

Default value

MSTP is shut down, while SSTP or RSTP is running.

Instruction

None

Example

The following example shows how to enable MSTP on a switch.

```
Router_config# spanning-tree mode mstp
Router_config#
```

8.4.2 spanning-tree mstp name

Syntax

spanning-tree mstp name *string*

no spanning-tree mstp name

To configure the MSTP name, run **spanning-tree mstp name *string***. To resume the default name, run **no spanning-tree mstp name**.

Parameter

Parameter	Description
<i>string</i>	A character string to configure the name, which contains up to 32 characters and is capital sensitive. Its default value is the MAC address of a switch.

Default value

Its default value is the MAC address of a switch.

Instruction

None

Example

The following example shows how to set the name of MSTP for a switch to **reg-01**.

```
Router_config# spanning-tree mstp name reg-01
Router_config#
```

8.4.3 spanning-tree mstp revision**Syntax**

spanning-tree mstp revision *value*

no spanning-tree mstp revision

To configure the MSTP revision number, run **spanning-tree mstp revision** *value*. To resume the default revision number, run **no spanning-tree mstp revision**.

Parameter

Parameter	Description
<i>value</i>	Revision number, which ranges between 0 and 65535 and whose default value is 0

Default value

The default value of the revision number is 0.

Instruction

None

Example

The following example shows how to set the revision number of MSTP to 100.

```
Router_config# spanning-tree mstp revision 100
Router_config#
```

8.4.4 spanning-tree mstp instance**Syntax**

spanning-tree mstp instance *instance-id* **vlan** *vlan-list*

no spanning-tree mstp instance *instance-id*

To map VLAN to MSTI, run **spanning-tree mstp instance** *instance-id* **vlan** *vlan-list*. To remap VLAN to CIST, run **no spanning-tree mstp instance** *instance-id*.

Parameter

Parameter	Description
<i>instance-id</i>	Instance ID of the spanning-tree, which stands for an MSTI Value range: 1-15
<i>vlan-list</i>	A VLAN list which is mapped to a spanning tree Value range: 1-4094

Default value

All VLANs are mapped to CIST (MST00).

Instruction

Instance ID is an independent value which stands for an STP instance.

The **vlan-list** parameter can stand for a VLAN group, such as VLANs 1,2 and3, VLANs 1-5 or VLANs 1,2,5-10.

Example

The following example shows how to map VLAN1 to STP instance 1, and VLANs 5, 7, 10-20 to STP instance 2 and then remap these VLANs to MST00.

```
Router_config# spanning-tree mstp instance 1 vlan 2
Router_config# spanning-tree mstp instance 2 vlan 5,7,10-20
Router_config# no spanning-tree mstp instance 2
```

8.4.5 spanning-tree mstp root

Syntax

```
spanning-tree mstp instance-id root {primary | secondary}
[ diameter net-diameter [ hello-time seconds ] ]
no spanning-tree mstp root
```

To set a designated STP instance to a primary or secondary root, run **spanning-tree mstp** *instance-id* **root** {primary | secondary}. To resume the default value of the bridge priority of an STP instance, run **no spanning-tree mstp root**.

The **diameter** command and the **hello time** command are allowed to modify the network diameter and the **hello-time** parameter.

Parameter

Parameter	Description
<i>instance-id</i>	Number of the STP instance, which ranges between 0 and 15
<i>primary</i>	Sets an STP instance to a primary root.
<i>secondary</i>	Sets an STP instance to a secondary root.
<i>net-diameter</i>	An optional parameter which presents the network diameter

	When instance-id is 0, net-diameter ranges between 2 and 7.
seconds	An optional parameter standing for the value of the Hello Time parameter, which ranges between 1 and 10 seconds

Default value

The default value of the bridge priority for all STP instances is 32768. The network diameter is 7, while Hello Time is 2 seconds.

Instruction

The **diameter** command and the **hello-time** command validate only when the **instance-id** parameter is 0.

In general, after the command to set the primary root is executed, the protocol automatically check the bridge ID of the current network's root and then sets the priority of the bridge ID to 24576, which guarantees that the current switch serves as the root of the STP instance. If the priority value of the network root is less than 24576, the protocol will automatically set the STP priority of the current bridge to a value which is 4096 smaller than the priority of the root. It deserves attention that 4096 is the step of the priority value of the bridge.

Different from primary root configuration, after the command to set the secondary root is executed, the protocol directly set the STP priority of the switch to 28672. In case that the priority value of other switches in the network is 32768 by default, the current switch serves as the secondary root.

Example

The following example shows how to set a switch to the primary root in CIST, and how to recalculate the time parameter of STP through **diameter 3** and **hello-time 3**, and then set the switch to the secondary root in MST01.

```
Router_config# spanning-tree mstp 0 root primary diameter 3 hello-time 3
Router_config# spanning-tree mstp 1 root secondary
```

8.4.6 spanning-tree mstp priority

Syntax

spanning-tree mstp *instance-id* priority *value*

no spanning-tree mstp priority

To configure the value of the bridge priority of a designated STP instance, run **spanning-tree mstp *instance-id* priority *value***. To resume the default value of the bridge priority, run **no spanning-tree mstp priority**.

Parameter

Parameter	Description
<i>instance-id</i>	Number of the STP instance, which ranges between 0 and 15
<i>value</i>	Value of the bridge priority, which can be one of the following values: 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672,

	32768, 36864, 40960, 45056, 49152, 53248, 57344, 61440.
--	---

Default value

The default value of the bridge priority for all STP instances is 32768.

Instruction

The priority values in each STP instance are independent and can be configured independently.

Example

The following example shows how to set the priority values of a switch in CIST and MST01 to 4096 and 8192 respectively.

```
Router_config# spanning-tree mstp 0 priority 4096
Router_config# spanning-tree mstp 1 priority 8192
```

8.4.7 spanning-tree mstp hello-time

Syntax

```
spanning-tree mstp hello-time seconds
no spanning-tree mstp hello-time
```

To configure the Hello Time of MSTP, run **spanning-tree mstp hello-time seconds**. To resume the default value of the Hello Time of MSTP, run **no spanning-tree mstp hello-time**.

Parameter

Parameter	Description
seconds	Value range: 1-10 seconds Default value: 2 seconds

Default value

2 seconds

Instruction

None

Example

The following example shows how to set the Hello Time parameter of MSTP to **10**.

```
Router_config# spanning-tree mstp hello-time 10
Router_config# no spanning-tree mstp hello-time
```

8.4.8 spanning-tree mstp forward-time

Syntax

spanning-tree mstp forward-time seconds

no spanning-tree mstp forward-time

To configure the **forward delay** parameter of MSTP, run **spanning-tree mstp forward-time seconds**. To resume the default value of the **forward delay** parameter of MSTP, run **no spanning-tree mstp forward-time**.

Parameter

Parameter	Description
seconds	Value range: 4-30 seconds Default value: 15 seconds

Default value

15 seconds

Instruction

None

Example

The following example shows how to set the **Forward Delay** parameter of MSTP to 10.

```
Router_config# spanning-tree mstp forward-time 10
Router_config# no spanning-tree mstp forward-time
```

8.4.9 spanning-tree mstp max-age

Syntax

spanning-tree mstp max-age seconds

no spanning-tree mstp max-age

To configure the **max age** parameter of MSTP, run **spanning-tree mstp max-age seconds**. To resume the default value of the **forward delay** parameter of MSTP, run **no spanning-tree mstp max-age**.

Parameter

Parameter	Description
seconds	Value range: 6-40 seconds Default value: 20 seconds

Default value

20 seconds

Instruction

None

Example

The following example shows how to set the **max age** parameter of MSTP to **10**.

```
Router_config# spanning-tree mstp max-age 10
Router_config# no spanning-tree mstp max-age
```

8.4.10 spanning-tree mstp diameter**Syntax**

```
spanning-tree mstp diameter net-diameter
no spanning-tree mstp diameter
```

To configure the network diameter of MSTP, run **spanning-tree mstp diameter** *net-diameter*. To resume the default value of the network diameter, run **no spanning-tree mstp diameter**.

Parameter

Parameter	Description
net-diameter	Value range: 2-7 Default value: 7

Default value

The default value of the network diameter is 7.

Instruction

The **net-diameter** parameter is not saved as an independent configuration in the switch. Only the time parameter which is modified through network diameter configuration can be saved. The **net-diameter** parameter is effective only to CIST. After configuration, the three time parameters of STP are automatically updated to a prior value.

It is recommended to modify the time parameter of STP through setting the root or network diameter, ensuring the reasonability of the time parameter.

Example

The following example shows how to set the network diameter of MSTP to 5 and then resume its default value.

```
Router_config# spanning-tree mstp diameter 5
Router_config# no spanning-tree mstp diameter
```

8.4.11 spanning-tree mstp max-hops**Syntax**

```
spanning-tree mstp max-hops hop-count
```

no spanning-tree mstp max-hops

To set the maximum hops of MSTP BPDU, run **spanning-tree mstp max-hops *hop-count***. To resume the default settings, run **no spanning-tree mstp max-hops**.

Parameter

Parameter	Description
hop-count	Value range: 1-40 Default value: 20

Default value

The default value of the maximum hops is 20.

Instruction

None

Example

The following example shows how to set the maximum hops of MSTP BPDU to **5** and then resume the default value.

```
Router_config# spanning-tree mstp max-hops 5
Router_config# no spanning-tree mstp max-hops
```

8.4.12 spanning-tree mstp port-priority**Syntax**

spanning-tree mstp *instance-id* port-priority *value*

no spanning-tree *instance-id* port-priority

To configure the port priority in the designated spanning-tree instance, run **spanning-tree mstp *instance-id* port-priority *value***. To resume the port priority to the default settings, run **no spanning-tree *instance-id* port-priority**.

Parameter

Parameter	Description
instance-id	ID of the STP instance, which ranges between 0 and 15
value	Value of the port priority, which can be one of the following values 0, 16, 32, 48, 64, 80, 96, 112 128, 144, 160, 176, 192, 208, 224, 240.

Default value

The port priority in all STP instances is 128 by default.

Instruction

None

Example

The following example shows how to set the priority value of port switchFastEthernet 4/1 in CIST to **16** and then resume the default value.

```
Router_config_sfe4/1# spanning-tree mstp 0 port-priority 16
Router_config_sfe4/1# no spanning-tree mstp 0 port-priority
```

8.4.13 spanning-tree mstp cost**Syntax**

spanning-tree mstp *instance-id* cost *value*

no spanning-tree mstp *instance-id* cost

To set the path cost of the spanning tree in the designated STP instance, run **spanning-tree mstp *instance-id* cost *value***. To resume the default value, run **no spanning-tree mstp *instance-id* cost**.

Parameter

Parameter	Description
instance-id	ID of the STP instance, which ranges between 0 and 15
value	Path cost of a port, which ranges between 1 and 200,000,000

Default value

The path cost depends on the connection rate of the port.

- 10 Mbps: 2000000
- 100 Mbps: 200000
- 1000 Mbps: 20000

Instruction

None

Example

The following example shows how to set the path cost of port switchFastEthernet 4/1 to 200 in CIST.

```
Router_config_sfe4/1# spanning-tree mstp 0 cost 200
Router_config_sfe4/1#
```

8.4.14 spanning-tree mstp edge**Syntax**

spanning-tree mstp edge { force-true | force-false | auto }

no spanning-tree mstp edge

To configure the MSTP edge of a port, run **spanning-tree mstp edge { force-true | force-false | auto }**. To resume the connection type to be automatic check, run **no spanning-tree mstp edge**.

Parameter

Parameter	Description
force-true	Set a port forcedly to be an edge port.
force-false	Set a port forcedly to be not an edge port.
auto	Checks the edge automatically (default).

Default value

MSTP will automatically check the edge port by default.

Instruction

None

Example

None

8.4.15 spanning-tree mstp point-to-point

Syntax

spanning-tree mstp point-to-point { force-true | force-false | auto }

no spanning-tree mstp point-to-point

To configure the connection type of a port, run **spanning-tree mstp point-to-point { force-true | force-false | auto }**. To resume the connection type to **auto-check**, run **no spanning-tree mstp point-to-point**.

Parameter

Parameter	Description
force-true	Sets the port connection mode to point-to-point .
force-false	Sets the port connection mode to sharing .
auto	Sets the port connection mode to auto-check (the default mode).

Default value

MSTP will automatically check the port connection mode by default.

Instruction

None

Example

The following example shows how to set the connection mode of port switchFastEthernet 4//1 to **sharing**.

```
Router_config_sfe4/1# spanning-tree mstp point-to-point force-false
Router_config_sfe4/1#
```

8.4.16 spanning-tree mstp mst-compatible**Syntax**

```
spanning-tree mstp mst-compatible
no spanning-tree mstp mst-compatible
```

To activate the MST-compatible mode, run **spanning-tree mstp mst-compatible**. To shut down the MST-compatible mode, run **no spanning-tree mstp mst-compatible**.

Parameter

None

Default value

The compatible mode is not activated by default and the switch cannot establish an area with other switches which transmit BPDU in compatible mode.

Instruction

After the compatible mode is enabled, you are recommended to set a connected switch which runs other MSTP to the root of CIST, securing that the switch can enter the compatible mode through receiving packets.

Example

The following example shows how to activate the MST-compatible mode of a switch in global configuration mode.

```
Router_config#spanning-tree mstp mst-compatible
```

8.4.17 spanning-tree mstp migration-check**Syntax**

```
spanning-tree mstp migration-check
```

To remove the STP information which is checked on a port and then restart the protocol transform process, run the previous command.

Parameter

None

Default value

None

Instruction

This command validates both in global configuration mode and in port configuration mode.

Example

The following example shows how to conduct the protocol transfer check on all ports and then conduct the second protocol transfer check on port switchFastEthernet 4/1.

```
Router_config# spanning-tree mstp migration-check
Router_config# interface f 0/1
Router_config_sfe4/1# spanning-tree mstp migration-check
```

8.4.18 show spanning-tree mstp**Syntax**

show spanning-tree mstp [instance *instance-id*]

To browse the MSTP information, run **show spanning-tree mstp [instance *instance-id*]**. If the **instance** parameter is not in the command syntax, the information about all spanning-tree instances will be displayed.

Parameter

Parameter	Description
instance-id	ID of the STP instance, which ranges between 0 and 15

Default value

None

Instruction

This command can be used in monitoring mode, global configuration mode or port mode.

Example

The following example shows how to browse all spanning-tree instances. MST00 stands for CIST, while Type stands for the connection type of the corresponding port.

```
Switch#show spanning-tree mstp
```

```
MST00      Vlans Mapped: 1,4-4094
Bridge     Address 00E0.0F64.8365 Priority 32768 (32768 mst-id 0)
Root       This bridge is the CIST and regional root
Configured Hello Time 2, Forward Delay 15, Max Age 20, Max Hops 20
Root Times Hello Time 2, Forward Delay 15, Max Age 20
```

Interface	Role	Sts	Cost	Pri.	Nbr	Type
<hr/>						
F0/1	Desg	FWD	200000	128.1		P2p
F0/3	Back	BLK	200000	128.3		P2p
F0/47	Desg	FWD	200000	128.47		Edge
MST01	Vlans Mapped: 2					
Bridge	Address 00E0.0F64.8365 Priority 32769 (32768 mst-id 1)					
Root	This bridge for MST01					
Interface	Role	Sts	Cost	Pri.	Nbr	Type
<hr/>						
F0/1	Desg	FWD	200000	128.1		P2p
MST02	Vlans Mapped: 3					
Bridge	Address 00E0.0F64.8365 Priority 32770 (32768 mst-id 2)					
Root	This bridge for MST02					
Interface	Role	Sts	Cost	Pri.	Nbr	Type
<hr/>						
F0/1	Desg	FWD	200000	128.1		P2p

8.4.19 show spanning-tree mstp region

Syntax

show spanning-tree mstp region

To browse the area configuration information about MSTP, run the previous command.

Parameter

None

Default value

None

Instruction

None

Example

In the following example, MST Config Table is to display the relationship between VLAN and spanning-tree instance.

Router_config# show spanning-tree mstp region

MST Region:

Name: [reg01]
Revision:[0]

MST Config Table:

Instance	VLAN IDs
-----	-----

0	1,4-4094
1	2
2	3

8.4.20 show spanning-tree mstp detail

Syntax

show spanning-tree mstp detail

To browse the detailed information about MSTP, run the previous command.

Parameter

None

Default value

None

Instruction

None

Example

The following example shows how to browse the detailed information about MSTP, which includes the port connection types and the configuration of optional attributes.

Switch#show spanning-tree mstp detail

```
MST00      Vlans Mapped: 1,4-4094
Bridge     Address 00E0.0F64.8365 Priority 32768 (32768 mst-id 0)
Root       This bridge is the CIST and regional root
Configured Hello Time 2, Forward Delay 15, Max Age 20, Max Hops 20
Root Times Hello Time 2, Forward Delay 15, Max Age 20

FastEthernet0/1 of MST00 is designated forwarding
Port Info          Port ID 128.1      Priority 128      Cost 200000
Designated Root    Address 00E0.0F64.8365  Priority 32768  Cost 0
CIST Regional Root Address 00E0.0F64.8365  Priority 32768  Cost 0
Designated Bridge  Address 00E0.0F64.8365  Priority 32768  Port ID 128.1
Edge Port: disabled           Link Type: point-to-point (auto)
Bpdu Guard: disabled (default)   Root Guard: disabled (default)
Loop Guard: disabled (default)
Timers: message expires in 0 sec, forward delay 0 sec, up time 662 sec
Number of transitions to forwarding state: 1
Bpdu sent 335, received 5
```

```
FastEthernet0/3 of MST00 is backup blocking
Port Info          Port ID 128.3      Priority 128      Cost 200000
Designated Root    Address 00E0.0F64.8365  Priority 32768  Cost 0
CIST Regional Root Address 00E0.0F64.8365  Priority 32768  Cost 0
Designated Bridge  Address 00E0.0F64.8365  Priority 32768  Port ID 128.1
Edge Port: disabled           Link Type: point-to-point (auto)
Bpdu Guard: disabled (default)   Root Guard: disabled (default)
```

Loop Guard: disabled (default)

Timers: message expires in 5 sec, forward delay 15 sec, up time 662 sec

Number of transitions to forwarding state: 0

Bpdu sent 5, received 335

FastEthernet0/47 of MST00 is designated forwarding

Port Info Port ID 128.47 Priority 128 Cost 200000

Designated Root Address 00E0.0F64.8365 Priority 32768 Cost 0

CIST Regional Root Address 00E0.0F64.8365 Priority 32768 Cost 0

Designated Bridge Address 00E0.0F64.8365 Priority 32768 Port ID 128.47

Edge Port: enabled (auto) Link Type: point-to-point (auto)

Bpdu Guard: disabled (default) Root Guard: disabled (default)

Loop Guard: disabled (default)

Timers: message expires in 0 sec, forward delay 0 sec, up time 1485 sec

Number of transitions to forwarding state: 1

Bpdu sent 744, received 0

MST01 Vlans Mapped: 2

Bridge Address 00E0.0F64.8365 Priority 32769 (32768 mst-id 1)

Root This bridge for MST01

FastEthernet0/1 of MST01 is designated forwarding

Port Info Port ID 128.1 Priority 128 Cost 200000

Designated Root Address 00E0.0F64.8365 Priority 32769 Cost 0

Desingated Bridge Address 00E0.0F64.8365 Priority 32769 Port ID 128.1

Timers: message expires in 0 sec, forward delay 0 sec, up time 662 sec

Number of transitions to forwarding state: 1

MST Config Message transmitted 335, received 0

MST02 Vlans Mapped: 3

Bridge Address 00E0.0F64.8365 Priority 32770 (32768 mst-id 2)

Root This bridge for MST02

FastEthernet0/1 of MST02 is designated forwarding

Port Info Port ID 128.1 Priority 128 Cost 200000

Designated Root Address 00E0.0F64.8365 Priority 32770 Cost 0

Desingated Bridge Address 00E0.0F64.8365 Priority 32770 Port ID 128.1

Timers: message expires in 0 sec, forward delay 0 sec, up time 662 sec

Number of transitions to forwarding state: 1

MST Config Message transmitted 335, received 0

8.4.21 show spanning-tree mstp interface

Syntax

show spanning-tree mstp interface *interface-id*

To browse the information about a port under MSTP, run the previous command.

Parameter

Parameter	Description
<i>interface-id</i>	Name of an interface, such as f0/1 and fastEthernet0/3

Default value

None

Instruction

None

Example

The following example shows how to browse the information about interface f0/1.

```
Switch#show spanning-tree mstp interface f0/1
```

FastEthernet0/1 of MST00 is designated forwarding

Port Info	Port ID 128.1	Priority 128	Cost 200000
Designated Root	Address 00E0.0F64.8365	Priority 32768	Cost 0
CIST Regional Root	Address 00E0.0F64.8365	Priority 32768	Cost 0
Designated Bridge	Address 00E0.0F64.8365	Priority 32768	Port ID 128.1
Edge Port:	disabled	Link Type:	point-to-point (auto)
Bpdu Guard:	disabled (default)	Root Guard:	disabled (default)
Loop Guard:	disabled (default)		
Timers:	message expires in 0 sec, forward delay 0 sec, up time 851 sec		
Number of transitions to forwarding state:	1		
Bpdu sent	430, received 5		

FastEthernet0/1 of MST01 is designated forwarding

Port Info	Port ID 128.1	Priority 128	Cost 200000
Designated Root	Address 00E0.0F64.8365	Priority 32769	Cost 0
Desingated Bridge	Address 00E0.0F64.8365	Priority 32769	Port ID 128.1
Timers:	message expires in 0 sec, forward delay 0 sec, up time 851 sec		
Number of transitions to forwarding state:	1		
MST Config Message transmitted	430, received 0		

FastEthernet0/1 of MST02 is designated forwarding

Port Info	Port ID 128.1	Priority 128	Cost 200000
Designated Root	Address 00E0.0F64.8365	Priority 32770	Cost 0
Desingated Bridge	Address 00E0.0F64.8365	Priority 32770	Port ID 128.1
Timers:	message expires in 0 sec, forward delay 0 sec, up time 851 sec		
Number of transitions to forwarding state:	1		
MST Config Message transmitted	430, received 0		

Instance Role Sts Cost Pri.Nbr Vlans Mapped

-----	-----	-----	-----	-----
0	Desg FWD 200000	128.1	1,4-4094	
1	Desg FWD 200000	128.1	2	
2	Desg FWD 200000	128.1	3	show spanning-tree mstp protocol-migration

Syntax**`show spanning-tree mstp protocol-migration`**

To browse the protocol transfer information on an interface under MSTP, run the previous command.

Parameter

None

Default value

None

Instruction

None

Example

The following example shows how to browse the information about protocol transfer on an interface. In the following example, interface f0/2 is running in 802.1D STP mode.

```
Switch#show spanning-tree mstp protocol-migration
```

MSTP Port Protocol Migration

Interface	Protocol	Info
F0/2		802.1D

8.5 Optional STP Attribute Configuration Commands

8.5.1 spanning-tree portfast

Syntax

spanning-tree portfast {bpdufilter default | bpduguard default | default}

no spanning-tree portfast {bpdufilter default | bpduguard default | default}

To configure the portfast attribute in global configuration mode, run **spanning-tree portfast {bpdufilter default | bpduguard default | default}**. To cancel this attribute in global configuration mode, run **no spanning-tree portfast {bpdufilter default | bpduguard default | default}**.

spanning-tree portfast [disable | trunk]

no spanning-tree portfast

To configure the portfast attribute in port configuration mode, run **spanning-tree portfast [disable | trunk]**. To cancel this attribute in port configuration mode, run **no spanning-tree portfast**.

Parameter

Parameter	Description
bpdufilter default	Starts the BPDU filtration.
bpduguard default	Starts the BPDU protection.

default	Means the default mode.
---------	-------------------------

Default value

This function is not enabled by default.

Description

The portfast attribute enables a port in SSTP/PVST mode to promptly enter the forwarding state without state change. This configuration invalidates in RSTP/MSTP mode.

After the portfast attribute is configured, it need be protected through BPDU Guard configuration or BPDU Filter configuration.

Command mode

Global or port configuration mode

Example

The following example shows how to enable the portfast attribute in global configuration mode.

```
Router_config# spanning-tree portfast default
Router_config#
```

The following example shows how to enable the attributes of port f0/0:

```
Switch(config_f0/0)# spanning-tree portfast
Switch(config_f0/0)#

```

8.5.2 spanning-tree bpduguard

Syntax

```
spanning-tree bpduguard {disable | enable}
no spanning-tree bpduguard
```

To configure BPDU Guard, run **spanning-tree bpduguard {disable | enable}**. To cancel BPDU Guard, run **no spanning-tree bpduguard**.

Parameter

None

Default value

This function is not enabled by default.

Instruction

In SSTP/PVST mode, if a port that has the BPDU Guard function and the Portfast function configured receives BPDU, this port will be mandatorily shut down. You have to configure the port manually to resume this port. In RSTP/MSTP mode, if a BPDU-Guard-configured port receives BPDU, the port will be set to the Blocking state in a period of time.

Command mode

Port configuration mode

Example

The following example shows how to enable BPDU protection on port f0/0.

```
Switch(config_f0/0)# spanning-tree bpduguard enable
Switch(config_f0/0)#

```

8.5.3 spanning-tree bpdufilter

Syntax

```
spanning-tree bpdufilter {disable | enable}
no spanning-tree bpdufilter
```

To configure the BPDU filtration, run **spanning-tree bpdufilter {disable | enable}**. To cancel the BPDU filtration, run **no spanning-tree bpdufilter**.

Parameter

None

Default value

This function is not enabled by default.

Description

In SSTP/PVST mode, a port which has the BPDU Filter function and the Port Fast function configured receives BPDU, the BPDU Filter attribute and the Port Fast attribute are automatically shut down. In this case, the port resumes to be a normal port which first enters the listening state, the learning state and then the forwarding state.

This function invalidates in RSTP/MSTP mode.

Command mode

Port configuration mode

Example

The following example shows how to enable BPDU filtration on port f0/0.

```
Switch(config_f0/0)# spanning-tree bpdufilter enable
Switch(config_f0/0)#

```

8.5.4 spanning-tree uplinkfast

Syntax

```
spanning-tree uplinkfast [max-update-rate pkts-per-second]
no spanning-tree uplinkfast [max-update-rate]
```

To configure the uplinkfast function, run **spanning-tree uplinkfast [max-update-rate pkts-per-second]**. To cancel the uplinkfast function, run **no spanning-tree uplinkfast [max-update-rate]**.

Parameter

None

Default value

This function is not enabled by default.

Instruction

The UplinkFast function validates only in Sstp/PVST mode.

Command mode

Global configuration mode

Example

The following example shows how to enable the UplinkFast attribute.

```
Router_config# spanning-tree uplinkfast  
Router_config#
```

8.5.5 spanning-tree backbonefast

Syntax

```
spanning-tree backbonefast  
no spanning-tree backbonefast
```

To configure the backbonefast function, run **spanning-tree backbonefast**. To cancel the backbonefast function, run **no spanning-tree backbonefast**.

Parameter

None

Default value

This function is not enabled by default.

Instruction

The backbonefast function validates only in Sstp/PVST mode.

Command mode

Global configuration mode

Example

The following example shows how to enable the backbonefast function:

```
Router_config# spanning-tree backbonefast
Router_config#
```

8.5.6 spanning-tree guard

Syntax

spanning-tree guard {loop | none | root}

no spanning-tree guard

To configure the Port Guard function, run **spanning-tree guard {loop | none | root}**. To cancel this function, run **no spanning-tree guard**.

Parameter

Parameter	Description
<i>loop</i>	Guard loop Range: 1-0*fe
<i>none</i>	Guard none Range: 48 bits
<i>root</i>	Guard root

Default value

This protection function is not enabled.

Instruction

The Root Guard attribute can prevent a port from serving as a root port after it receives a higher-priority BPDU.

The Loop Guard attribute can protect a port after it changes from a root port or an alternate port to a designated port. This function can prevent a port from generating a loop when the port cannot receive BPDU continuously.

Command mode

Port configuration mode

Example

The following example shows how to prevent port f0/0 from being the root:

```
Switch(config_f0/0)# spanning-tree guard root
Switch(config_f0/0)#

```

8.5.7 spanning-tree loopguard

Syntax

spanning-tree loopguard default

To configure the guard loop in global configuration mode, run **spanning-tree loopguard default**. To cancel the guard loop in global configuration mode, run **no spanning-tree loopguard default**.

Parameter

None

Default value

None

Description

None

Command mode

Global configuration mode

Example

The following example shows how to enable the loopguard function.

```
Router_config# spanning-tree loopguard default
Router_config#
```

8.5.8 spanning-tree fast-aging

Syntax

spanning-tree fast-aging

no spanning-tree fast-aging

The two commands above are used to enable or disable the fast aging mechanism of the address table.

spanning-tree fast-aging protection

no spanning-tree fast-aging protection

The two commands above are used to enable or disable the protection of fast aging of the address table.

spanning-tree fast-aging protection time value

no spanning-tree fast-aging protection time

The two commands above are used to configure the time of aging protection of the address table.

Parameter

Parameter	Description
<i>value</i>	Stands for the aging protection time. 10-60 seconds (15 seconds by default)

Default value

Fast aging is enabled by default. However protection is not enabled by default.

Description

switches of version 2.0.1M and the previous versions, and hi-end switches of version 4.0.00 and the previous versions do not support the aging protection of the address table.

Command mode

Global configuration mode

Example

The following example shows how to enable fast aging protection and set the protection time to 30 seconds.

```
Router_config#spanning-tree fast-aging protection  
Router_config#spanning-tree fast-aging protection time 30
```

8.5.9 spanning-tree fast-aging flush-fdb

Syntax

```
spanning-tree fast-aging flush-fdb  
no spanning-tree fast-aging flush-fdb
```

To enable or disable FDB-Flush, run the previous commands.

Parameter

None

Default value

There is no default settings.

Description

Please configure this command under the guide of technical engineers.

switches of version 2.0.1M and the previous versions, and hi-end switches of version 4.0.00 and the previous versions do not support the aging protection of the address table.

FDB-Flush is independent of fast aging. FDB-Flush can be configured while **no spanning-tree fast-aging** is configured. Fast aging protection is invalid to FDB-Flush.

Command mode

Global configuration mode

Example

The following example shows how to disable fast aging and enable FDB-Flush.

```
Router_config#no spanning-tree fast-aging  
Router_config#spanning-tree fast-aging flush-fdb
```

Chapter 9 802.1x Configuration Commands

9.1 802.1x Configuration Commands

The following commands are used to configure 802.1x:

- dot1x enable
- dot1x port-control
- dot1x multiple-hosts
- dot1x default
- dot1x max-req
- dot1x reauth-max
- dot1x re-authentication
- dot1x timeout quiet-period
- dot1x timeout re-authperiod
- dot1x timeout tx-period
- dot1x user-permit
- dot1x authentication method
- dot1x accounting enable
- dot1x accounting method
- dot1x authen-type、dot1x authentication type
- dot1x guest-vlan
- dot1x guest-vlan id
- dot1x forbid multi-network-adapter
- aaa authentication dot1x
- debug dot1x error
- debug dot1x state
- debug dot1x packet
- show dot1x

9.1.1 dot1x enable

Syntax

```
dot1x enable
no dot1x enable
```

Parameter

None

Default value

None

Instruction

If the 802.1x function is not enabled, you cannot start it on an interface. If the 802.1x function is forbidden, all interfaces have no the 802.1x function, and at the same time, all 802.1x packets will not be received by CPU but can be forwarded in VLAN like normal multicast packets.

Command mode

Global configuration mode

Example

The following example shows how to enable dot1x.

```
Router_config#dot1x enable
Router_config#
```

9.1.2 dot1x port-control

Syntax

```
dot1x port-control {auto/force-authorized/force-unauthorized}
no dot1x port-control
```

Parameter

Parameter	Description
auto	Enables the 802.1x authentication mode.
force-authorized	Cancels the 802.1x authentication.
force-unauthorized	Sets the interface to unauthorized mandatorily.

Default value

force-authorized

Instruction

The 802.1x protocol is an interface-based two-layer authentication mode. You can run the **auto** command to enable the authentication mode. This authentication mode can be configured only on the physical interface and the interface's attributes cannot include VLAN backbone, dynamical access, security port or listening port.

Command mode

Port configuration mode

Example

The following example shows how to enable 802.1x on interface f0/24.

```
Switch(config_f0/24)# dot1x port-control auto
Switch(config_f0/24)#{
```

The following example shows how to firstly set interface f0/23 to the VLAN backbone and then enable 802.1x.

```
Switch(config_f0/23)#switchport mode trunk
Switch(config_f0/23)#dot1x port-control auto
802.1x Control Failed, 802.1x cannot cmd on vlanTrunk port(f0/23)
Switch(config_f0/23)#{
```

9.1.3 dot1x multiple-hosts

Syntax

dot1x multiple-hosts
no dot1x multiple-hosts

Parameter

None

Default value

The 802.1x multi-client authentication is disabled.

Instruction

The 802.1x authentication is mainly for the single host user. At this time, the switch allows only one user to conduct the authentication and the access control. However, sometimes the port may connect multiple hosts through 802.1x-unsupported switching device, such as switch 1108. In order to make these hosts' users access successfully, you can enable the multi-host port access function.

After an interface is configured to 802.1x multi-client authentication, the switch will perform authentication to different host users. If the authentication passes, the switch allows these hosts to access through the switch itself.

Command mode

Port configuration mode

Example

The following example shows how to enable multi-client interface authentication on interface f0/24.

```
Switch(config_f0/24)# dot1x multiple-hosts
Switch(config_f0/24)#{
```

9.1.4 dot1x default

Syntax

dot1x default

Parameter

None

Default value

None

Instruction

This command is used to resume all global configurations to the default settings.

Command mode

Global configuration mode

Example

The following example shows how to resume all dot1x configuration parameters to their default values.

```
Router_config#dot1x default
Router_config#
```

9.1.5 dot1x max-req

Syntax

```
dot1x max-req count
no dot1x max-req
```

Parameter

Parameter	Description
<i>count</i>	Maximum times of identity authentication requests, ranging between 1 and 10

Default value

2

Instruction

You can modify the maximum times of ID authentication request according to different network environments, ensuring that the authentication between the client and the authentication server passes.

Command mode

Global configuration mode

Example

The following example shows how to configure the maximum times of dot1x identity authentication request to **4**.

```
Router_config#dot1x max-req 4
Router_config#
```

9.1.6 dot1x reauth-max

Syntax

```
dot1x reauth-max count
no dot1x reauth-max
```

Parameter

Parameter	Description
<i>count</i>	Maximum authentication re-try times, ranging between 1 and 10

Default value

4

Instruction

This command is used to set the authentication retry times. If the retry times exceeds the maximum retry times and the client has no response, the authentication is mounted.

Command mode

Global configuration mode

Example

The following example shows how to configure the maximum times of dot1x identity authentication request to **5**.

```
Router_config#dot1x reauth-max 5
Router_config#
```

9.1.7 dot1x re-authentication

Syntax

```
dot1x re-authentication
no dot1x re-authentication
```

Parameter

None

Default value

None

Instruction

After an interface passes authentication, the interface will still perform authentication to hosts in a certain period. You can run **dot1x timeout re-autjperiod** to configure the period.

Command mode

Global configuration mode

Example

The following example shows how to enable the re-authentication function.

```
Router_config#dot1x re-authentication
Router_config#
```

9.1.8 dot1x timeout quiet-period**Syntax**

```
dot1x timeout quiet-period time
no dot1x timeout quiet-period
```

Parameter

Parameter	Description
<i>time</i>	Period for restarting dot1x authentication, ranging between 0 and 65535 seconds

Default value

60s

Instruction

There is a certain period when the switch cannot perform any authentication after the previous authentication fails.

Command mode

Global configuration mode

Example

The following example shows how to set the value of **quiet-period** to 40.

```
Router_config#dot1x timeout quiet-period 40
Router_config#
```

9.1.9 dot1x timeout re-authperiod

Syntax

```
dot1x timeout re-authperiod time
no dot1x timeout re-authperiod
```

Parameter

Parameter	Description
<i>time</i>	dot1x re-authentication period, ranging between 1 and 4294967295s

Default value

3600s

Instruction

This command validates only when the re-authentication function is enabled.

Command mode

Global configuration mode

Example

The following example shows how to set the dot1x re-authentication period to 7200 seconds.

```
Router_config# dot1x timeout re-authperiod 7200
Router_config#
```

9.1.10 dot1x timeout tx-period

Syntax

```
dot1x timeout tx-period time
no dot1x timeout tx-period
```

Parameter

Parameter	Description
<i>time</i>	Time which ranges between 1 and 65535 seconds

Default value

30s

Instruction

This command is used to set the client's authentication request response interval. If the interval is exceeded, the switch would retransmit the authentication request.

Command mode

Global configuration mode

Example

The following example shows how to set the transmission frequency to 24.

```
Switch(config_f0/0)# dot1x timeout tx-period 24
Switch(config_f0/0)#

```

9.1.11 dot1x user-permit

Syntax

```
dot1x user-permit xxx yyy zzz
no dot1x user-permit
```

Parameter

Parameter	Description
xxx	A user name
yyy	A user name
zzz	A user name

Default value

No user is bound and all users would pass.

Instruction

This command can be used to bind users on an interface. Each interface can be bound to up to eight users. When the 802.1x authentication is enabled, the authentication is performed only to those bound users. However, to those unbound users, the authentication must fail.

Command mode

Port configuration mode

Example

The following example shows how to bind users a, b, c and d on interface switchFastEthernet 4/1.

```
Router_config_sfe4/1# dot1x user-permit a b c d
Router_config_sfe4/1#
```

9.1.12 dot1x authentication method

Syntax

```
dot1x authentication method xxx
no dot1x authentication method
```

Parameter

Parameter	Description
xxx	Method name

Default value

Default method

Instruction

This command is used to configure the authentication method which must be one of authentication methods provided by AAA. One interface only uses one authentication method. When AAA performs authentication to the 802.1x user, AAA would select the configured authentication method to perform the authentication.

Command mode

Port configuration mode

Example

The following example shows how to set the authentication method on interface switchFastEthernet 4/1 to **abcd** which applies the local username for authentication and that on interface f0/2 to **efgh** which applies the remote radius authentication.

```
Router_config #aaa authentication dot1x abcd local
Router_config #aaa authentication dot1x efgh group radius
Router_config #int switchFastEthernet 4/1
Router_config_sfe4/1# dot1x authentication method abcd
Router_config_sfe4/1# int switchFastEthernet 4/2
Router_config_sfe4/2# dot1x authentication method efgh
```

9.1.13 dot1x authen-type、dot1x authentication type

Syntax

```
dot1x authen-type {chap|eap}
no dot1x authen-type
```

To configure the dot1x authentication type in global configuration mode, run **dot1x authen-type**; to resume the default settings in global configuration mode, run **no dot1x authen-type**.

```
dot1x authentication type {chap|eap}
no dot1x authentication type
```

To configure the dot1x authentication type on an interface, run **dot1x authentication type**; to resume the default settings on an interface, run **no dot1x authentication type**.

Parameter

None

Default value

The default dot1x authentication type is **chap**.

The default dot1x authentication type in global configuration mode is also used applied by default in interface configuration mode.

Instruction

This command is used to configure the authentication class, while the authentication class decides whether AAA uses the CHAP authentication or the EAP authentication. If the CHAP authentication is used, the challenge required by MD5 is locally generated; if the EAP authentication is used, the challenge is generated on the authentication server. Only one authentication mode can be applied to one interface. By default, the authentication mode is applied in global mode. When an authentication mode is configured for an interface, the authentication mode will be always used on the interface unless the negative form of the command is run to resume the default settings.

Command mode

Interface or global configuration mode

Example

The following example shows how to set the authentication type on interface switchFastEthernet 4/1 to **chap** and the global authentication type to **eap**.

```
Router_config #dot1x authen-type eap
Router_config #int switchFastEthernet 4/1
Router_config_sfe4/1# dot1x authentication type chap
```

9.1.14 dot1x guest-vlan

Syntax

dot1x guest-vlan

no dot1x guest-vlan

To enable the guest-vlan function of dot1x in global configuration mode, run **dot1x guest-vlan**. To disable the guest-vlan function of dot1x in global configuration mode, run **no dot1x guest-vlan**.

Parameter

None

Default value

The guest-vlan function of dot1x is shut down in global configuration mode by default.

Instruction

After the guest-vlan function is enabled, the corresponding port can be grouped into the guest vlan and specific network access rights are attributed to the port if a guest terminal does not respond.

This command is used together with the **dot1x guest-vlan id** command.

Command mode

Global configuration mode

Example

The following example shows how to enable the guest-vlan function in global configuration mode.

```
Router_config #dot1x guest-vlan
```

9.1.15 dot1x guest-vlan id

Syntax

```
dot1x guest-vlan id  
no dot1x guest-vlan
```

To configure the value of **dot1x guest-vlan id** on an interface, run **dot1x guest-vlan id**; to resume the default value **0**, run **no dot1x guest-vlan**.

Parameter

ID: stands for the value of guest vlan, which can be any vlan ID configured in the system.

Default value

0

Instruction

After the guest-vlan function is enabled, the corresponding port can be grouped into the guest vlan and specific network access rights are attributed to the port if a guest terminal does not respond.

This command is used together with the **dot1x guest-vlan id** command.

Command mode

Port configuration mode

Example

The following example shows how to configure the guest-vlan id in port configuration commands.

```
Switch(config_if) #dot1x guest-vlan 2
```

9.1.16 aaa authentication dot1x

Syntax

```
aaa authentication dot1x {default} method1 [method2...]
no aaa authentication dot1x {default} method1 [method2...]
```

Parameter

Parameter	Description
default	Uses the following method when a user is authenticated.
<i>method1 [method2...]</i>	enable 、 group radius、 line、 local、 local-case、 none

Default value

There is no authentication.

Instruction

The **method** parameter provides a series of methods to authenticate the password of the client host. You'd better adopt the radius as the AAA authentication mode of 802.1x. You can also use the local configuration data for authentication, such as user password saved in the local configuration.

Command mode

Global configuration mode

Example

The following example shows how to configure the dot1x authentication method to **radius**.

```
Router_config#aaa authentication dot1x default group radius
Router_config#
```

9.1.17 debug dot1x error

Syntax

```
debug dot1x error
```

Parameter

None

Default value

None

Instruction

This command is used to export all error information occurred during dot1x running.
The error information can help locating the errors.

9.1.18 debug dot1x state**Syntax****debug dot1x state****Parameter**

None

Default value

None

Instruction

The following shows the format of information output:

```
2003-3-18 17:40:09 802.1x:AuthSM(F0/10) state Connecting-> Authenticating, event rxResId  
2003-3-18 17:40:09 802.1x:F0/10 Create user for Enter authentication  
2003-3-18 17:40:09 802.1x:BauthSM(F0/10) state Idle-> Response, event authStart  
2003-3-18 17:40:09 802.1x:F0/10 user "myname" denied, Authentication Force Failed  
2003-3-18 17:40:09 802.1x:F0/10 Authentication Fail  
2003-3-18 17:40:09 802.1x:BauthSM(F0/10) state Response-> Fail, event aFail
```

9.1.19 debug dot1x packet**Syntax****debug dot1x packet****Parameter**

None

Default value

None

Instruction

```
2003-3-18 17:40:09 802.1x:F0/10 Tx --> Supplicant(0008.74bb.d21f)  
EAPOL ver:01, type:00, len:5  
EAP code:01, id:03, type:01, len:5  
00  
2003-3-18 17:40:09 802.1x:F0/10 Rx <-- Supplicant(0008.74bb.d21f)  
EAPOL ver:01, type:00, len:10
```

```
EAP code:02, id:03, type:01, len:10
62 64 63 6f 6d a5
```

9.1.20 show dot1x

Syntax

show dot1x [interface *intf-id*]

To display the 802.1x configuration information, run the previous command.

Parameter

Parameter	Description
<i>intf-id</i>	Stands for a specific physical interface.

Default value

None

Instruction

This command is used to display the 802.1x configuration information.

Command mode

EXEC

Example

The following example shows how to configure **dot1x port-control auto** on interface f0/10.

```
Router_config#sho dot1x
802.1X Parameters
reAuthen      No
reAuth-Period 3
quiet-Period  10
Tx-Period     30
Supp-timeout  30
Server-timeout 30
reAuth-max    4
max-request   2
authen-type   Eap
IEEE 802.1x on port F0/10 enabled
Authorized      Yes
Authen Type     Eap
Authen Method   default
Permit Users   All Users
Multiple Hosts Disallowed
Supplicant      aaa(0008.74bb.d21f)
Current Identifier 21
Authenticator State Machine
State          Authenticated
```

Reauth Count	0
Backend State Machine	
State	Idle
Request Count	0
Identifier (Server)	20
Port Timer Machine	
Auth Tx While Time	16
Backend While Time	16
reAuth Wait Time	3
Hold Wait Time	0