

# Interface Range Commands

## I Table of Contents

### 1.1 Interface Range

Syntax **interface range** *type slot*/*<port1-port2 | port3>*[, *<port1-port2|port3>*]

#### Parameters

Name	Usage Guidelines	Value Range
<i>type</i>	Port type	All reasonable port types, except the manager port on the main control board of the cabinet-like switch
<i>slot</i>	Slot number	All legal slot numbers
<i>port1</i>	Starting value of the port numbers	All legal port numbers on a slot
<i>port2</i>	Ending value of the port numbers	All legal port numbers on a slot which are no smaller than port 1
<i>port3</i>	An independent port	All legal port numbers on a slot

#### Default Value

None

#### Usage Guidelines

The command can be used to enter the interface range mode.

#### Example

The following example shows how to enter the port configuration mode of gigabit Ethernet port 1, 2, 3 or 4 on slot 0.

```
switch_config# interface range gigaEthernet 0/1-4  
switch_config_if_range# Note:
```

There is no space at the neither side of the symbol “\_” and the symbol “,”.