

S5864H Hardware Installation Manual

Table of Contents

Chapter 1 S5864H Introduction.....	1
1.1 Appearance Description for Standard Configuration.....	1
1.2 S5864H Systematic Characteristic Parameters.....	2
1.3 ROHS Description.....	4
Chapter 2 Installation Preparation.....	5
2.1 Caution of Usage.....	5
2.2 Safety Advice.....	5
2.2.1 Safety Principles.....	5
2.2.2 Safety Notices.....	5
2.2.3 Safety Principles for Live Working.....	6
2.2.4 Electrostatic Discharge Damage Prevention.....	7
2.3 Requirements for Common Locations.....	7
2.3.1 Environment.....	7
2.3.2 Location Configuration Prevention.....	7
2.3.3 Cabinet Configuration.....	7
2.3.4 Power Requirements.....	8
2.4 Installation Tools and Device.....	8
Chapter 3 Installing the S5864H Switch.....	9
3.1 Installation Flow of S5864H.....	9
3.2 Installing the Machine Box of the Switch.....	9
3.2.1 Installing the Machine Box on the Desk.....	9
3.2.2 Installing the Machine Box on the Cabinet.....	10
3.3 Connecting the Port.....	10

3.3.1 Connecting the Console Port.....	10
3.3.2 Connecting 10GE Ethernet SFP+ Ports.....	12
3.3.3 Connecting Ethernet Management Ports.....	12
3.3.4 Connecting 40GE Ethernet QSFP+ Ports.....	13

3.3.5 Connecting 100/40GE Ethernet QSFP28 Optical Ports.....	14
1.3.6 USB Interface.....	16
3.4 Checking After Installation.....	16
Chapter 4 Maintaining Switch.....	17
4.1 Opening the Machine Box.....	17
4.2 Closing Machine Box.....	18
Chapter 5 Hardware Fault Analysis.....	19
5.1 Fault Separation.....	19
5.1.1 Faults Relative with Power and Cooling System.....	19
5.1.2 Faults Relative with Port, Cable and Connection.....	19

Chapter 1 S5864H Introduction

The section describes the characteristics and parameters of S5864H and gives an overview of S5864H.

1.1 Appearance Description for Standard Configuration

The built-in ports of S5864H are: 48 10Gbps SFP+ ports, 4 100Gbps QSFP28 optical ports, 2 40Gbps QSFP+ optical ports, 1 console port, 1 gigabit management port and 1 USB interface. See table 1-1.

Table 1-1 Attributes of the built-in port

Port	Attribute
10Gbps optical port	SFP+ interface, with LINK/ACT indicator
40Gbps optical port	QSFP+ interface, with LINK/ACT indicator
100Gbps optical port	QSFP28 interface, with LINK/ACT indicator
Console port	RJ45 interface, a rate of 9600bps
Ethernet management port	RJ45 interface
USB interface	USB interface

S5864H has 4 hot swap fans and 2 two power sockets at its back.




Figure 1- 1 Front template of the S5864H switch

Table 1-2 Parts at the front template of the S5864H switch

No.	Abbrev.	Name	Description
1, 2, 5, 6	SFP+	10GE Ethernet optical ports	48 10GE SFP+ ports
3	QSFP28	100/40Gbps Ethernet optical ports	4 QSPFP28 100/40Gbps optical ports
4	QSFP+	40Gbps Ethernet optical ports	2 QSFP+ 40Gbps optical ports
7	LED	Indicator	System/power supply indicators




Figure 1- 2 Back template of the S5864H switch

Table 1-3 Parts at the back template of the S5864H switch

No.	Abbrev.	Name	Description
1,3,9,11	/	Grounding column	The grounding must be fine.
2, 10	POWER	AC power supply	AC220V, dual power backup, hot swap
7	CONSOLE	Console port	Manages the switch locally.
8	MNG	Gigabit Ethernet management ports	Gigabit Ethernet Base-T ports, 100/1000Base-T ports
6	USB	USB	USB port
5	LED	Indicator	System/power supply indicator
4	FAN	Fan	Four hot swap fan modules

1.2 S5864H Systematic Characteristic Parameters

Protocol standard	Supported standard	IEEE 802.1d Spanning Tree Protocol IEEE 802.1s multiple spanning trees IEEE 802.1p Class of Service IEEE 802.1q tagged VLAN IEEE 802.3x Flow control IEEE 802.3z asymmetric flow control IEEE 802.3ad Link aggregation
	IP routing protocol standard	RFC 1058 RIP RFC 1723 RIP v2 RFC 1583 OSPF v2

	Network management standard	RFC 1157 SNMP v1/v2 RFC 1213 MIB II RFC 1757 RMON 1,2,3,9
Hardware characteristics	Memory	Flash Memory: 64M Bytes SDRAM: 512Mbytes;
	Standard configuration	48 SFP+ 10GE optical ports; 4 QSFP28 100/40Gbps optical ports; 2 QSFP+ 40Gbps optical ports; 1 Console port 1 USB interface 1 gigabit management interface
	Dimensions mm (WxDxH)	442.5x404x44
	Operating temperature/humidity	0°C~40°C; 10%~85% non-condensing
	Storage temperature/humidity	-40°C~80°C; 5%~95% non-condensing
	Power characteristics	Input voltage: AC100~240V, Input frequency: 47~63Hz Input current: 3A (MAX) Output voltage: 12VDC Output current: 40A(MAX)
	Full power consumption	<316W

1.3 ROHS Description

Part Name	Toxic or Hazardous Substances and Elements					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
PCBA	○	○	○	○	○	○
Metal Parts	○	○	○	○	○	○
Plastic & Polymer Parts	○	○	○	○	○	○
Cables & Cable Assemblies	○	○	○	○	○	○
Packaging Materials & Assemblies	○	○	○	○	○	○

This table is prepared in accordance with the provisions of SJ/T11364.

O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T26572

X: Indicates that said hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T26572.

The referenced environment-friendly use period logo is determined based on the normal operating conditions (such as temperature and humidity)

(NOTE: These statements apply only to the China RoHS regulations.)



Chapter 2 Installation Preparation

2.1 Caution of Usage

Similar to other electronic products, the semiconductor chip easily gets damaged if you power on or off abruptly and frequently. To restart up the switch of S5864H, you have to open the power on-off after the power is cut down for three to five seconds.

Avoid severe collision or falling down from the height to protect the parts in the switch.

Use correct outside ports to connect the switch of S5864H. Do not put the Ethernet plug into the console port (RJ45 8-line socket). Similarly, do not put the console cable into the console port (RJ45 8-line socket).

Note:

- 1) When you plug or dial the power line, keep the power line horizontal with the power socket.
- 2) When the lifetime of our products ends, handle them according to national laws and regulations, or send these products to our company for collective processing.

2.2 Safety Advice

2.2.1 Safety Principles

- Keep dustless and clean during or after the installation.
- Put the cover at the safe place.
- Put tools at the right place where they are not easily falling down.
- Put on relatively tight clothes, fasten the tie or scarf well and roll up the sleeve, avoiding stumbling the machine box.
- Put on the protective glasses if the environment may cause damage to your eyes.
- Avoid incorrect operations that may cause damage to human or devices.

2.2.2 Safety Notices

The safety notices mentioned here means that improper operation may lead to body damage.

- Read the installation guide carefully before you operate the system.
- Only professionals are allowed to install or replace the switch.
- Pull out the AC power socket and close the direct-current power before operating on the machine box or working beside the power source.
- The final configuration of products must comply with relative national laws and regulations.

2.2.3 Safety Principles for Live Working

When you work under electricity, following the following principles:

- Put off ornaments, such as ring, necklace, watch and bracelet, before you operate under live working. When metal articles connect the power to the ground, short circuit happens and components may be damaged.
- Pull out the AC power socket and close the direct-current power before operating on the machine box or working beside the power source.
- When the power is on, do not touch the power.
- Correctly connect the device and the power socket.
- Only professionals are allowed to operate and maintain the device.
- Read the installation guide carefully before the system is powered on.

Note:

- 1) Check potential dangers, such as the humid floor, ungrounded extensible power line and tatty power line.
- 2) Install the emergent on-off at the working room for turning off the power when trouble happens.
- 3) Turn off the power on-off of the switch and plug off the power line before installing or uninstalling the machine box or working beside the power.
- 4) Do not work alone if potential dangers exist.
- 5) Cut off the power before checkout.
- 6) If trouble happens, take the following measures:
 - A. Cut off the system's power.
 - B. Alarm.
 - C. Take proper measures to help persons who are hit by the disaster. Artificial respiration is needed if necessary.
 - D. Seek for medical help, or judge the loss and seek for available help.

2.2.4 Electrostatic Discharge Damage Prevention

Electrostatic discharge may damage devices and circuits. Improper treatment may cause the switch to malfunction completely or discontinuously.

Move or locate the devices according to the measures of electrostatic discharge prevention, ensuring the machine box connects the ground. Another measure is to wear the static-proof hand ring. If there is no hand ring, use the metal clip with the metal cable to clip the unpainted metal part of the machine box. In this case, the static is discharged to the ground through the metal cable of the clip. You can also discharge the static to the ground through your body.

2.3 Requirements for Common Locations

This part describes the requirements for the installation locations.

2.3.1 Environment

The switch can be installed on the desk or the cabinet. The location of the machine box, cabinet planning and indoor cabling are very important for normal system's function. Short distance between devices, bad ventilation and untouchable control plate will cause maintenance problems, systematic faulty and breakdown.

For location planning and device locating, refer to section 2.3.2 "Location Configuration Prevention".

2.3.2 Location Configuration Prevention

The following preventive measures assist you to design the proper environment for the switch.

- Make sure that the workshop is well-ventilated, the heat of electrical devices is well-discharged and sufficient air circulation is provided for device cooling.
- Avoid to damage devices by following the electrostatic discharge prevention procedure.
- Put the machine box at the place where cool air can blow off the heat inside the machine box. Make sure the machine box is sealed because the opened machine box will reverse the cool air flow.

2.3.3 Cabinet Configuration

The following content assists you to make a proper cabinet configuration:

- Each device on the cabinet gives off heat when it runs. Therefore, the sealed cabinet must have the heat-discharge outlet and the cooling fan. Do not put the devices too close, avoiding bad ventilation.
- When you install the machine box at the open cabinet, prevent the frame of the cabinet from blocking the airway of the machine box.
- Ensure that nice ventilation is provided for the devices installed at the bottom of the cabinet.
- The clapboard separates exhaust gas and inflow air, and boost cool air to flow in the machine box. The best location of the clapboard is decided by the air flow mode in the machine box, which can be obtained through different location tests.

2.3.4 Power Requirements

Make sure that the power supply has nice grounding and the power at the input side of the switch is reliable. The voltage control can be installed if necessary. At least a 240 V, 10A fuse or a breaker is provided in the phase line if you prepare the short-circuit prevention measures for a building.

Caution:

If the power supply system does not have good grounding, or the input power disturbs too much and excessive pulses exist, the error code rate of communication devices increases and even the hardware system will be damaged.

2.4 Installation Tools and Device

The tools and devices to install the S5864H switch are not provided by the S5864H switch. You yourself need to prepare them. The following are the tools and devices needed for the typical installation of the S5864H switch:


- Screwdriver
- Static armguard
- Bolt
- Ethernet cable
- Other Ethernet terminal devices
- Control terminal

Chapter 3 Installing the S5864H Switch

Caution:

Only professionals are allowed to install or replace the devices.

3.1 Installation Flow of S5864H



3.2 Installing the Machine Box of the Switch

The installation of the machine box has two modes:

- Installing the machine box on the desk
- Installing the machine box on the cabinet

3.2.1 Installing the Machine Box on the Desk

The S5864H switch can be directly put on the smooth and safe desk.

Note:

Do not put things weighing 4.5 kg or over 4.5 kg on the top of the switch.

3.2.2 Installing the Machine Box on the Cabinet

The machine box of the switch is fixed on the cabinet through the brackets. When you fix the brackets, the front template of the switch faces forward. The detailed operations are shown in Figure 3-1.




Figure 3- 1 Fixing the machine box of the switch

Caution: The switch shown in figure 3-1 does not represent the material S5864H.

After the brackets are installed, install the switch on the cabinet. See Figure 3-2.




Figure 3- 2 Installing the switch on the cabinet

3.3 Connecting the Port

3.3.1 Connecting the Console Port

The rate of the console port is a value of 9600bps. It has a standard RJ45 plug. It is odd-even optional and has traffic control. After you connect the console port to the serial port of the terminal, such as STAR-510G+ or PC through a console cable, you can configure and monitor the switch of S5864H by running a terminal emulation software, such as super Windows terminal. The cable is provided according to the host. The communication parameters of the terminal serial port can be set to a rate of 9600bps, eight data bits, one stop bit, no sum check bit and traffic control.




Figure 3-3 RJ-45 connector of the console port

The RJ45 connector of the console port is shown in the following figure. The RJ45 plug corresponds to the RJ45 socket, whose pins can be aligned from left to right with the value from 1 to 8.




Figure 3-4 Connecting the console port of S5864H and computer

Caution: The switch shown in figure 3-3 does not represent the material S5864H.

Table 3- 1 Pins of the console port

NO.	Name	Remark
1	NC	No connection
2	RXD	Input
3	NC	No connection

4	TXD	Output
5	NC	No connection
7	NC	No connection
8	SG	GND

Note:

The cable is used to connect the console port of R7308 router and the outside monitoring device. One end is RJ45 8-core plug, and the other end of the console cable is 9-hole plug (DB9). The RJ45 plug is put into the socket of the console port on the S5864H switch. The inner line connection in the cable is shown in figure 3-1. The console cable is numbered as RLC0301.




Figure 3-5 The inner connection of the 1-to-8 RJ45 cable (RLC0301)

3.3.2 Connecting 10GE Ethernet SFP+ Ports

The S5864H switch has 48 10GE SFP+ ports. Each port has its corresponding indicator: 1~48. You can connect the SFP+ optical module to the SFP+ port and then you can connect other Ethernet terminal devices through the optical cable.




Figure 3-6 Connecting the 10GE SFP+ port and other Ethernet terminals

Caution: The switch shown in figure 3-5 does not represent the material S5864H.

3.3.3 Connecting Ethernet Management Ports

S5864H provides 1 10/100/1000Base-T port. Each port has its corresponding MNG indicator. The indicators are used to indicate the LINK/ACT state. The ports can connect other Ethernet terminal devices through the UTP port and the direct-through or cross network cable. The numbering order of the pins in the UTP port is the same as that in the console port. See figure 3-6.




Figure 3-7 RJ-45 connector on the console port

Because the 10/100/1000Base-T ports of S5864H support the MDI/MDIX self-identification of the cable, S5864H can adopt five types of direct-through/cross network cables when it connects other Ethernet terminals.





Figure 3-8 Connecting the 1000Base-TX port and other Ethernet terminals

Caution: The switch shown in figure 3-8 does not represent the material S5864H.

Table 3- 2 Pins of Gigabit RJ45

No.	Pin Name	Remark
1	Sending/receiving the normal phase of data 0	TP0+
2	Sending/receiving the paraphase of the data 0	TP0-
3	Sending/receiving the normal phase of data 1	TP1+
4	Sending/receiving the normal phase of data 2	TP2+
5	Sending/receiving the paraphase of the data 2	TP2-
6	Sending/receiving the paraphase of the data 1	TP1-



7	Sending/receiving the normal phase of data 3	TP3+
8	Sending/receiving the paraphase of the data 3	TP3-

3.3.4 Connecting 40GE Ethernet QSFP+ Ports

S5864H provides with 2 40GE QSFP+ ports. Each port has its corresponding indicator: 40G 1~2.

The four ports can be configured into 2 modes:

1. Set the rate of the port to 40Gbps

You can connect the QSFP+ optical port to the QSFP+ optical module and then you can connect other Ethernet terminal devices with 40GE optical ports through the optical cable.

Figure 3-9 Connecting the 40GE QSFP+ port and other Ethernet terminals

2. Set the ports to 4 10GE ports

You can connect the QSFP+ optical module to the optical port and then you can connect other Ethernet terminal devices with 10GE optical ports through the MPO-4*LC optical cable.




Figure 3-10 Connecting the 40GE QSFP+ port (breaks out into 4 10GE ports) and other Ethernet terminals

Caution: The switch shown in figure 3-9 does not represent the material S5864H.

3.3.5 Connecting 100/40GE Ethernet QSFP28 Optical Ports

S5864H provides with 4 100/40GE QSFP28 ports. Each port has its corresponding indicator: 40G/100G 1~4.

In use, the four ports can be configured into three modes:

1. Set the rate of the port to 100Gbps

You can connect the QSFP28 optical module to the optical port and then you can connect other Ethernet terminal devices with 100Gbps optical ports through the optical cable.




Figure 3-11 Connecting 100GE QSFP28 optical ports and other Ethernet terminals

2. Set the rate of the port to 40Gbps

You can connect the QSFP+ optical module to the optical port and then you can connect other Ethernet terminal devices with 40Gbps optical ports through the optical cable.




Figure 3-12 Connecting 100GE QSFP28 optical ports (configured to be 40GE ports) and other Ethernet terminals

3. Set the rate of the port to 4 10Gbps ports

You can connect the QSFP+ optical module to the optical port and then you can connect other Ethernet terminal devices with 40Gbps optical ports through the MPO-4*LC optical cable.




Figure 3-13 Connecting 100GE QSFP28 optical ports (configured to be 4 10GE ports) and other Ethernet terminals

1.3.6 USB Interface

S5864H provides with 1 USB2.0 interface.



Figure 3-14 Connecting USB2.0 interface

3.4 Checking After Installation

Before electrically starting up the switch, perform the following checkups after the switch is installed:

- If the switch is installed on the cabinet, check whether the installation point between the cabinet and the switch is strong. If the switch is installed on the desk, check whether there is enough space for the switch to discharge its heat and whether the desk is stable.
- Check whether the connected power meets the requirements of the switch.
- Check whether the grounding line is correctly connected.

- Check whether the switch is correctly connected to other terminal devices.

Chapter 4 Maintaining Switch

Caution:

- 1) Before opening the machine box, make sure that you have released the static you carried and then turn off the power on-off of the switch. Before operating any step in Appendix B, read the section "Safety Advice".
- 2) Before performing operations beside the power source or on the machine box, turn off the power on-off and plug out the power cable.

4.1 Opening the Machine Box

This section describes how to open the cover of the switch, required tools and operation methods.

Caution:

When the power cable still connects the power source, do not touch it.

When you open the cover the switch, you may use the following tools:

- Crossed screwdriver
- Static armguard


Perform the following steps to open the cover of the switch:

- (1) Turn off the power on-off of the switch.
- (2) Plug out all cables connected the back of the switch.
- (3) Take out the bolt from the machine box with the screwdriver.

Note:

The machine box comprises of two parts: cover and bottom.

- (4) Open the cover by holding two sides of the cover towards the direction of the arrow key shown in the following figure:



Caution: The switch shown in the above figure does not represent the material S5864H.

- (5) When the cover is opened, put it aside. The mainboard of the system appears.


Note:

After taking off the cover, put it horizontally and avoid it to be crushed or collided. Otherwise, the machine box is hard to install.

4.2 Closing Machine Box

The section mainly describes how to put the cover and close the machine box. Do as follows:

- (1) Put them well according to their locations and joint them together along their sides. See the following figure.



- (2) When the cover and the bottom are closely tied, let the cover slide the slot of the front template at the bottom.
- (3) Nail the bolt and screw it tightly with the screwdriver.
- (4) Reinstall the switch on the cabinet or the desk.
- (5) Reconnect all cables of the switch.

Chapter 5 Hardware Fault Analysis

The part describes how to remove the fault from the switch.

5.1 Fault Separation

The key for resolving the systematic faults is to separate the fault from the system. You can compare what the system is doing with what the system should do to detect the fault. You need to check the following subsystems:

- Power and cooling systems—power and fan
- Port, cable and connection—ports on the front template of the switch and the cables connecting these ports

5.1.1 Faults Relative with Power and Cooling System

Do the following checkups to help remove the fault:

- When the power on-off is at the “ON” location, check whether the fan works normally. If the fan does not work well, check the fan.
- The working temperature of the switch is from 0 to 40 Celsius degrees. If the switch is too hot, check whether the air outlet and air inlet are clean and then do relative operations in section 2.3 “Requirements for Common Locations”.
- If the switch cannot be started and the “PWRA/PWRB” indicator is off, check the power.

5.1.2 Faults Relative with Port, Cable and Connection

Do the following checkups to help remove the fault:

- If the port of the switch cannot be linked, check whether the cable is correctly connected and whether the peer connection is normal.
- If the power on-off is at the “ON” location, check the power source and the power cable.
- If the console port does not work after the system is started up, check whether the console port is set to a baud rate of 9600 bps, eight data bits, no sum check bit, one stop bit and no traffic control.

5.2 Indicator Description

The LED indicator shows that the switch is running. The following table shows the indicators of the S5864H switch and their description:

Abbrev.	Name	Description
PWRA	Power indicator A	If the power supply A of the switch is powered on, the indicator is on.
PWRA	Power indicator B	If the power supply B of the switch is powered on, the indicator is on.
SYS	System indicator	If the system indicator flickers, the system works well. If the indicator is off or always on, the system is abnormally started.
MNG	Management port indicator	If the indicator is always on, the port is normally linked. If the indicator is not on, the port is not linked. If the indicator is off, the port is not linked. If the indicator flickers, there is data transmission.

1~48 (LINK/ACT)	SFP+ port indicators	<p>If the indicator is always on, the port is normally linked.</p> <p>If the indicator is off, the port is not linked.</p> <p>If the port indicator flickers, there is data transmission.</p>
40G 1~2	QSFP+ port indicators	<p>1. working in the mode of 40GE</p> <p>If the indicator is always on, the port is normally linked.</p> <p>If the indicator is off, the port is not linked.</p> <p>If the indicator flickers, there is data transmission.</p> <p>2. The 40GE port breaks out into 4 10GE ports</p> <p>The 4 indicators turns on every 5 seconds by turns, which shows the 10GE port state of the BREAKOUT indicator.</p>
40G/100G 1~4	QSFP28 port indicators	<p>1. working in the mode of 100GE</p> <p>If the indicator is always on, the port is normally linked.</p>
		<p>If the indicator is off, the port is not linked.</p> <p>If the indicator flickers, there is data transmission.</p> <p>2. working in the mode of 40GE</p> <p>If the indicator is always on, the port is normally lined.</p> <p>If the indicator is off, the port is not linked.</p> <p>If the indicator flickers, there is data transmission.</p> <p>3. The 40GE port breaks out into 4 10GE ports</p> <p>The 4 indicators turns on every 5 seconds by turns, which shows the 10GE port state of the BREAKOUT indicator.</p>

<p>40GE BREAKOUT(1~4)</p>	<p>The 40GE port breaks out into 4 10GE port indicators.</p>	<ol style="list-style-type: none"> 1. Working in the mode of 40GE, the indicator of BREAKOUT is off 2. The 40GE port breaks out into 4 10GE ports, which combines with QSFP+ port indicators. <p>If the indicator of QSFP+ is on, the four indicators of 40GE BREAKOUT correspond to LINK/ACT state of the 4 10GE ports of the QSFP+ port</p>
-------------------------------	--	---




Figure 5- 1 SFP+ port indicator




Figure 5-2 40GE BREAKOUT indicator




Figure 5-3 QSFP+ port indicator




Figure 5-4 QSFP28 port indicator




Figure 5-5 Backplane Indicator

Copyright Claims

Without the written approval of the company , any person or group cannot transcribe, copy or change partial or all contents of this manual, and must not broadcast it in any manner.

Trademark claims

Trademarks, product names, service names and company names, which are written in this manual but do not belong to the company, belong to their owners respectively.

Disclaimer of warranty provides no evident or hinted guarantee towards the contents of this manual. In no event, except for the company's breach of law, shall the company be liable for incidental, consequential, indirect or special damages of any kind or for loss of profits or revenue or loss of business arising out of or relating to this manual.

Note: Customer shall not be notified of this manual's content amendments.