

Link Aggregation Configuration

Table of Contents

Link Aggregation Configuration	1
Table of Contents	1
Chapter 1 Configuring Port Aggregation	1
1.1 Overview.....	1
1.2 Port Aggregation Configuration Task List.....	1
1.3 Port Aggregation Configuration Task.....	1
1.3.1 Configuring Logical Channel Used for Aggregation	1
1.3.2 Physical Port Aggregation	2
1.3.3 Selecting the Load Balance Mode after Port Aggregation	2
1.3.4 Monitoring the Concrete Condition of Port Aggregation	3

Chapter 1 Configuring Port Aggregation

This chapter describes how to set the port aggregation of the OLT.

1.1 Overview

Port aggregation is binding the physical ports with the same attribute together, so as to establish a logic channel. To aggregate multiple physical ports into a logical channel, you can use static aggregation or LACP protocol for negotiation. In the case when the static aggregation is used, it is required that the link of the physical port should be up, and the VLAN attribute of aggregation port and physical port should be identical, and then this port will be aggregated to the logical channel, regardless of whether the current port accords with the conditions of port aggregation and whether the port that connects with the physical port accords with the aggregation conditions.

Port aggregation of the OLT supports following operation modes and functions:

(1) Static aggregation control

After the settings of physical ports are bound to a logical port, you need not worry whether these physical ports can be bound to a logical port. You must deem that these ports can be bound to a logical port.

(2) Aggregation control of LACP dynamic negotiation

After physical ports are bound to a logical port, only the physical ports under LACP negotiation can be bound to a logical port and other ports cannot be bound to the logical port.

(3) Flow balance of port aggregation is supported.

After port aggregation, the data flow of the aggregation port will be distributed to each aggregated physical port.

OLT only supports port aggregation on the uplink port, but not on the PON port.

1.2 Port Aggregation Configuration Task List

Configuring logical channel used for aggregation

- (1) Aggregation of physical port
- (2) Selects the load balance mode after port aggregation.
- (3) Monitoring the concrete condition of port aggregation

1.3 Port Aggregation Configuration Task

1.3.1 Configuring Logical Channel Used for Aggregation

Configuring logical channel used to aggregation

Use the following command to configure the logical channel:

Command	Purpose
interface port-aggregator id	Configures aggregated logical channel.

1.3.2 Physical Port Aggregation

To aggregate multiple physical ports into a logical channel, you can use static aggregation or LACP protocol for negotiation.

In the case when the static aggregation is used, it is required that the link of the physical port should be up, and the VLAN attribute of aggregation port and physical port should be identical, and then this port will be aggregated to the logical channel, regardless of whether the current port accords with the conditions of port aggregation and whether the port that connects with the physical port accords with the aggregation conditions.

Use LACP and the ports can be aggregated after the negotiations both in the local end and the opposite end pass. Prerequisites for ports to be aggregated: The link of the port must be up and the port should be negotiated to full-duplex mode. The speed of all physical ports should be same during aggregation process, that is, if there is one physical port that has been aggregated successfully, then the speed of the second physical port must be the same as the first configured one. Also the vlan attributes of all physical ports must be identical to the aggregated port.

LACP packets are exchanged between ports in two modes: Active — Places a port into an active negotiating state, in which the port initiates negotiations with remote ports by sending LACP packets. Passive — Places a port into a passive negotiating state, in which the port responds to LACP packets it receives but does not initiate LACP negotiation. In this mode, the port channel group attaches the interface to the bundle. If both ports use Passive method, then the aggregation fails. This is because both sides will wait for the other side to launch aggregation negotiation process.

VLAN attributes: PVID, Trunk attribute, vlan-allowed range and vlan-untagged range.

Use the following command to perform aggregation on the uplink ports:

Command	Purpose
aggregator-group <i>agg-id</i> mode { lacp static }	Configures aggregation option of the physical port.

1.3.3 Selecting the Load Balance Mode after Port Aggregation

You can select the load share method to ensure that all ports can share the data traffic after the aggregation of all physical ports. The OLT can provide up to eight load balance strategy. The strategies not given in the document are not recommended.

src-mac

It is to share the data traffic according to the source MAC address, that is, the message with same MAC address attributes is to get through a physical port.

dst-mac

It is to share the data traffic according to the destination MAC address, that is, the message with same MAC address attributes is to get through a physical port.

both-mac

It is to share the data traffic according to source and destination MAC addresses, that is, the message with same MAC address attributes is to get through a physical port.

src-ip

It is to share the data traffic according to the source IP address, that is, the message with same IP address attributes is to get through a physical port.

dst-ip

It is to share the data traffic according to the destination IP address, that is, the message with same IP address attributes is to get through a physical port.

both-ip

It is to share the data traffic according to the destination and source IP addresses, that is, the message with same IP address attributes is to get through a physical port.

Use the following command to configure load balance method:

Command	Purpose
aggregator-group load-balance	Configures load balance method.

1.3.4 Monitoring the Concrete Condition of Port Aggregation

Use the following command to monitor port aggregation state in EXEC mode:

Command	Purpose
show aggregator-group [id] {detail brief summary}	Displays port aggregation state.